



## INSTALLATION AND OPERATING INSTRUCTIONS

2-jaw parallel gripper, electric  
GEH6000IL

3-jaw concentric gripper, electric  
GED6000IL

DDOC00212

THE KNOW-HOW FACTORY



## Glossary

| Term                     | Explanation   |
|--------------------------|---|
| ActualPosition           | Value of the current jaw position [1/100 mm]  |
| Adjust                   | Starts the travel routing stored in the product to teach the BasePosition and WorkPosition.   |
| BasePosition             | Outer jaw position<br>Depending on the application, this can be the base position or the work position.   |
| ControlWord              | Activation of the product<br>Only one bit is permitted to be active in the ControlWord. The value 0 is also permitted.  |
| DeviceMode               | Used to select gripping profiles as well as the additional help modes in the product.   |
| Diagnosis                | If an error occurs, outputs a diagnostic code that can be compared with the error list.   |
| DIR                      | Direction/24 V DC supply line<br>Depending on the product, this signal is used to move the gripper jaws.  |
| Error                    | Fault   |
| GND                      | Abbreviation for ground connection  |
| GripForce                | Setting the gripping force  |
| Offset                   | Correction value  |
| PositionTolerance        | Tolerance range for TeachPosition<br>The value of the parameter acts in both directions.  |
| ShiftPosition            | ShiftPosition is a switching position between pre-positioning and gripper movement.   |
| StatusWord               | Summary of binary states of the product that can be returned as information to the control system.  |
| STO/Safe Torque OFF      | Safety function of drives that prevents any torque from being generated in case of an emergency stop, even if the product is still connected to the voltage supply. |
| Teach                    | Adoption of the ActualPosition as the TeachPosition   |
| TeachPosition            | Taught-in workpiece position  |
| Traversing routine       | Defined procedure for movement of the gripper jaws  |
| Travel path              | Path on which the gripper jaws travel.  |
| WorkpieceNo              | Number of the selected workpiece recipe   |
| WorkPosition             | Inner jaw position<br>Depending on the application, this can be the standby position or the work position.  |
| Workpiece loss detection | Function which, in case of workpiece loss, causes the product to move to the end position.  |

**Content**

- 1 Supporting documents ..... 5
  - 1.1 Notices and graphics in the installation and operating instructions ..... 5
- 2 Safety notices ..... 6
- 3 Proper use ..... 8
- 4 Personnel qualification ..... 9
  - 4.1 Electricians ..... 9
  - 4.2 Specialists ..... 9
  - 4.3 Instructed personnel..... 9
  - 4.4 Service personnel..... 9
  - 4.5 Additional qualifications ..... 9
- 5 Product description ..... 10
  - 5.1 Possible applications..... 10
  - 5.2 Type plate ..... 11
- 6 Functional description ..... 12
  - 6.1 LED status display ..... 12
  - 6.2 Verified configuration examples ..... 12
  - 6.3 Self-locking mechanism ..... 12
- 7 Technical data ..... 13
- 8 Accessories/scope of delivery ..... 13
- 9 Transportation/storage/preservation ..... 13
- 10 Installation ..... 14
  - 10.1 Installing GEH6000IL ..... 15
  - 10.2 Installing GED6000IL ..... 15
  - 10.3 Safe shutoff for products with IO-Link..... 16
    - 10.3.1 Safe shutoff for grippers with IO-Link and without an STO cable ..... 16
    - 10.3.2 Safe shutoff for grippers with IO-Link and with an STO cable ..... 17
  - 10.4 Installing the energy supply ..... 18
    - 10.4.1 Pin assignment ..... 18
    - 10.4.2 B12-Y-5IL Y-cable pin assignment..... 19
    - 10.4.3 Pin assignment for products with an STO connection ..... 20
  - 10.5 Wiring..... 20
  - 10.6 Static charge ..... 21
  - 10.7 Heat dissipation ..... 21
  - 10.8 Installing accessories ..... 21
- 11 Commissioning ..... 22
  - 11.1 Process data ..... 22
  - 11.2 IODD Import ..... 23
  - 11.3 Handshake Data Transfer Method..... 23
  - 11.4 Parameters ..... 24
    - 11.4.1 ControlWord..... 24
    - 11.4.2 DeviceMode ..... 25
    - 11.4.3 Basic commands ..... 26
    - 11.4.4 WorkpieceNo ..... 27
    - 11.4.5 PositionTolerance ..... 27
    - 11.4.6 GripForce ..... 28
    - 11.4.7 DriveVelocity ..... 28
    - 11.4.8 BasePosition ..... 28
    - 11.4.9 ShiftPosition ..... 29
    - 11.4.10 TeachPosition..... 29

|         |   |    |
|---------|---|----|
| 11.4.11 | WorkPosition .....                                    | 29 |
| 11.4.12 | StatusWord .....                                      | 30 |
| 11.4.13 | Diagnosis .....                                       | 31 |
| 11.4.14 | ActualPosition .....                                  | 31 |
| 11.5    | Cold start .....                                      | 32 |
| 11.6    | Minimum travel path .....                             | 32 |
| 11.7    | Referencing by Homing .....                           | 33 |
| 11.7.1  | DeviceMode 10 .....                                   | 34 |
| 11.7.2  | DeviceMode 14 .....                                   | 34 |
| 11.7.3  | DeviceMode 16 .....                                   | 35 |
| 11.7.4  | DeviceMode 17 .....                                   | 36 |
| 11.8    | Movement profiles GEH6xxxIL-03-B/GED6xxxIL-03-A ..... | 37 |
| 11.8.1  | Positioning profiles .....                            | 38 |
| 11.8.2  | Force profiles .....                                  | 39 |
| 11.9    | Movement profiles GEH6xxxIL-31-B/GED6xxxIL-31-A ..... | 45 |
| 11.9.1  | DeviceModes .....                                     | 45 |
| 11.9.2  | Positioning profiles .....                            | 46 |
| 11.9.3  | Force profiles .....                                  | 47 |
| 11.10   | Interrupting the voltage supply .....                 | 53 |
| 11.11   | Easy Startup .....                                    | 53 |
| 11.12   | Starting the data transfer .....                      | 54 |
| 11.13   | Quickstart Basic Parameters .....                     | 55 |
| 11.14   | Starting the gripping movement .....                  | 56 |
| 11.15   | Repeated movements in the same direction .....        | 56 |
| 11.16   | Recipe examples .....                                 | 57 |
| 11.16.1 | Save recipe .....                                     | 57 |
| 11.16.2 | Loading a recipe .....                                | 58 |
| 12      | Operation .....                                       | 59 |
| 12.1    | Emergency release for GEH6000IL .....                 | 59 |
| 12.2    | Emergency release for GED6000IL .....                 | 60 |
| 13      | Gripping force charts .....                           | 60 |
| 14      | Error diagnosis .....                                 | 61 |
| 15      | Table with acyclic data (ISDU) .....                  | 64 |
| 16      | Maintenance .....                                     | 67 |
| 16.1    | Testing the STO safety function .....                 | 68 |
| 17      | Decommissioning/disposal .....                        | 69 |
| 18      | RoHS declaration .....                                | 70 |
| 19      | Declaration of Incorporation .....                    | 71 |
| 20      | Declaration of Conformity .....                       | 72 |

## 1 Supporting documents

### NOTICE



Read through the installation and operating instructions before installing or working with the product.

The installation and operating instructions contain important notes for your personal safety. They must be read and understood by all persons who work with or handle the product during any phase of the product lifetime.



The documents listed below are available for download on our website [www.zimmer-group.com](http://www.zimmer-group.com).

- Installation and operating instructions
  - Catalogs, drawings, CAD data, performance data
  - Information on accessories
  - Technical data sheets
  - General Terms and Conditions, including warranty information.
- ⇒ Only those documents currently available on the website are valid.

In these installation and operating instructions, "product" refers to the product designation on the title page!

### 1.1 Notices and graphics in the installation and operating instructions

#### DANGER



This notice warns of an imminent danger to the life and health of people. Ignoring these notices can lead to serious injury or even death.

- ▶ You absolutely must comply with the described measures for avoiding these dangers!
- ⇒ The warning symbols are assigned according to the type of danger.

#### WARNING



This notice warns of a situation that is potentially hazardous to personal health. Ignoring these notices can cause serious injury or damage to health.

- ▶ You absolutely must comply with the described measures for avoiding these dangers!
- ⇒ The warning symbols are assigned according to the type of danger.

#### CAUTION



This notice warns of a situation that is potentially hazardous to persons. Ignoring these notices can cause minor, reversible injuries.

- ▶ You absolutely must comply with the described measures for avoiding these dangers!
- ⇒ The warning symbols are assigned according to the type of danger.

#### NOTICE



This notice warns of possible material and environmental damage. Ignoring these notices can result in damage to the product or the environment.

- ▶ You absolutely must comply with the described measures for avoiding these dangers!
- ⇒ The warning symbols are assigned according to the type of danger.

#### INFORMATION



This category contains useful tips for handling the product efficiently. Failure to observe these tips will not result in damage to the product. This information does not include any information relevant to health or workplace safety.

## 2 Safety notices

### WARNING



#### Suspended loads can cause injury

Falling loads can cause severe injuries.

- ▶ Always keep an adequate safety distance from suspended loads.
- ▶ Do not stand or walk underneath suspended loads.

### CAUTION



#### Risk of injury and material damage in case of non-compliance

Installation, commissioning, maintenance and repairs may only be performed by qualified specialists in accordance with these installation and operating instructions.

The installation shall be made by qualified installation personnel and should conform to all national and local codes.

The product is state-of-the-art.

The following are examples of situations in which the product may cause a hazard:

- The product is not properly installed, used or maintained.
- The product is not used for its designated purpose.
- The locally applicable regulations, laws, directives or guidelines are not observed.
- ▶ The product may only be used in accordance with these installation and operating instructions and the product's technical data. Any changes or additions to the intended use of the product, as well as modifications to the product, such as those in the following examples, require the written permission of the manufacturer:
  - Use of the product under extreme conditions, such as aggressive fluids or abrasive dusts
  - Additional drilled holes or threads
- ⇒ Zimmer GmbH shall accept no liability for any damage caused by improper use. The operator bears sole responsibility.
- ▶ Make sure that the power supply is disconnected before you mount, adjust, modify, maintain or repair the product.
- ▶ Whenever work is carried out on the product, make sure that the product cannot be actuated by mistake.
- ▶ Perform maintenance tasks, renovation work or attachment work outside of the machine's danger zone when possible.
- ▶ Do not reach into the operational range of the product.
- ▶ Always adhere to the required maintenance intervals.
- ▶ When using the product under extreme conditions, adjust the maintenance interval according to the degree of contamination.
- ▶ Check the completeness and tightening torques of all mounting screws.

**CAUTION****Notes and handling regulations for electrostatically sensitive components**

Electrostatically sensitive components are individual components, integrated circuits or assemblies that can be damaged by electrostatic fields or electrostatic discharge.

- ▶ When handling electrostatic components, make sure that persons, the work area and packaging are all fully grounded.
- ▶ Touch electronic components only in appropriately identified areas with conductive flooring and only if:
  - You are grounded by means of special bracelets.
  - You wear shoes that are suitable and approved for the discharge of electrostatic charges.
- ▶ Do not bring electronic assemblies into contact with plastics and parts of clothing that have plastic content.
- ▶ Store electronic assemblies on conductive underlays only.
- ▶ Do not install electronic assemblies in the vicinity of data back-up devices or monitors (monitor distance > 100 mm).
- ▶ Perform measurements on electronic assemblies only if:
  - The measuring instrument is grounded (e.g. via a ground conductor).
  - The measuring head is momentarily discharged before measuring with a floating measuring instrument.

### 3 Proper use

#### NOTICE



#### Material damage and malfunction in case of non-compliance

The product is only to be used in its original state with its original accessories, with no unauthorized changes and within the stipulated parameter limits and operating conditions.

Any other or secondary use is deemed improper.

- ▶ Operate the product only in compliance with the associated installation and operating instructions.
- ▶ Operate the product only when it is in a technical condition that corresponds to the guaranteed parameters and operating conditions.
- ⇒ Zimmer GmbH shall accept no liability for any damage caused by improper use. The operator bears sole responsibility.

- The product is designed exclusively for electric operation using a 24 V DC power supply with Class 2.
- The product must always be mounted on materials that dissipate heat.
- The product is intended for industrial use.
- The product is to be used as intended in enclosed rooms for temporary gripping, handling and holding.
- The product is not suitable for clamping workpieces during a machining process.
- Direct contact with perishable goods/food is not permitted.



## 4 Personnel qualification

### WARNING



#### **Inadequate qualification can cause injury and material damage**

If inadequately qualified personnel perform work on the product, this can cause serious injuries and significant material damage.

- ▶ All work on the product must be performed by qualified personnel.
- ▶ Before working with the product, read the document in its entirety and make sure that you have understood everything.
- ▶ Observe country-specific accident prevention regulations and the general safety notices.

The following qualifications are a prerequisite for performing various work on the product.

#### **4.1 Electricians**

Electricians are able to perform work on electrical systems, can recognize and avoid possible dangers and know the relevant standards and provisions due to their technical training, knowledge and experience.

#### **4.2 Specialists**

Specialists are able to perform the assigned work, can recognize and avoid possible dangers and know the relevant standards and provisions due to their technical training, knowledge and experience.

#### **4.3 Instructed personnel**

Instructed personnel have been trained by the operating company on the tasks and possible dangers of improper behavior.

#### **4.4 Service personnel**

Service personnel are able to perform the assigned work and can recognize and avoid possible dangers due to their technical training, knowledge and experience.

#### **4.5 Additional qualifications**


Persons who work with the product must be familiar with the valid safety regulations and laws as well as the standards, guidelines and laws listed in this document.

Personnel who work with the product must have facility-issued authorization to commission, program, configure, operate, maintain and also decommission this product.


## 5 Product description

The products are 2-jaw parallel grippers of the GEH6000IL series and 3-jaw concentric grippers of the GED6000IL series. A mechanical self-locking mechanism is available depending on the product variant.

### GEH6000IL



### GED6000IL




- ① Removable centering sleeve
- ② Gripper jaw
- ③ Power supply

### 5.1 Possible applications


#### Outside gripping

The product can be used for outside gripping.  
MoveToWork command



#### Inside gripping

The product can be used for inside gripping.  
MoveToBase command




## 5.2 Type plate

A type plate is attached to the product.

The type plate shows the part number and serial number.

① Article number

② Confirmation number



## 6 Functional description

The gripper jaws of the GEH6000IL series are arranged parallel to each other on two opposing guide rails and can be moved relative to each other.

The gripper jaws of the GED6000IL series are arranged parallel to each other on three guide rails offset at a 120° angle.


The force of the motor is transmitted by a worm drive. A pinion and a rack generate the movement of the gripper jaws and synchronize these movements.

Despite its small installation space, the product is suited for gripping a wide range of form-fit and frictional fit parts.

The product can be easily integrated into the existing control system.

The gripping force can be adapted optimally to the workpiece conditions via IO-Link.

### 6.1 LED status display



- ① TeachPosition
- ② Error
- ③ Power supply
- ④ WorkPosition
- ⑤ BasePosition

### 6.2 Verified configuration examples

#### INFORMATION



- ▶ You can find the information in the technical data sheet on our website.
- ▶ Please contact Customer Service if you have any questions.

### 6.3 Self-locking mechanism

#### INFORMATION



The product has a mechanical self-locking mechanism to ensure that the workpiece remains held by the product in the event of power supply loss or failure (e.g. an emergency stop).

The self-locking mechanism is not available for the products GEH60xxIL-31-B and GED60xxIL-31-A.

- ▶ Please contact Customer Service if you have any questions.

## 7 Technical data

### INFORMATION



- ▶ You can find the information in the technical data sheet on our website.
- ▶ This data varies within the series, depending on the specific design.

## 8 Accessories/scope of delivery

### INFORMATION



- ▶ If any accessories not sold or authorized by Zimmer GmbH are used, the function of the product cannot be guaranteed. Zimmer GmbH accessories are specifically tailored to the individual products.
- ▶ For optional accessories and those included in the scope of delivery, refer to our website.

## 9 Transportation/storage/preservation

- ▶ Transport and storage of the product must be done only with the original packaging.
- ▶ If the product has already been installed on the superordinate machine unit, care must be taken during transport to ensure that no unexpected movements can occur.
  - ▶ Before commissioning the product and after transport, check all power and communication connections as well as all mechanical connections.
- ▶ If the product is stored for an extended period, the following points are to be observed:
  - ▶ Keep the storage location as dust-free and dry as possible.
  - ▶ Avoid temperature fluctuations.
  - ▶ Avoid wind/drafts/water condensation formation.
  - ▶ Pack the product and do not expose it to direct sunlight during storage.
- ▶ Clean all components. There must be no soiling left on the components.
- ▶ Visually inspect all components.
- ▶ Remove all foreign substances.
- ▶ Properly remove potential corrosion spots.
- ▶ Close electrical connections using suitable covers.

## 10 Installation

### WARNING



#### Risk of injury due to uncontrolled movements

Risk of injury in case of unexpected movement of the machine or system into which the product is to be installed.

- ▶ Switch off the energy supply of the machine before any work.
- ▶ Secure the power supply against being switched on unintentionally.
- ▶ Check the machine for any residual energy that may be present.

### CAUTION



#### Risk of injury due to uncontrolled movements

Risk of injury in the event of uncontrolled movement of the product when the power supply is connected.

- ▶ Switch off the power supply to the machine before carrying out any work.
- ▶ Secure the power supply against being switched on unintentionally.
- ▶ Check the machine for any residual energy that may be present.

### Assembly requirements

|                                       |      |
|---------------------------------------|------|
| Permissible flatness tolerance [mm]   | 0,03 |
| Strength class of the mounting screws | 8.8  |

### INFORMATION



Further installation information:


- The mounting screws are not included in the scope of delivery.

- ▶ Install the product on an appropriate mounting surface in accordance with the flatness specifications.
- ▶ Make sure that the mounting piece is sufficiently rigid.
- ▶ Ensure the cleanliness of the connection surfaces.
- ▶ Please note the permitted tightening torques of the mounting screws at [www.zimmer-group.com/en/td](http://www.zimmer-group.com/en/td).

### 10.1 Installing GEH6000IL

The product can be installed from multiple sides.

- ▶ Insert the straight pins or the centering sleeves into the provided fits on the product.
- The type of positioning varies within the series.
- ▶ Use the centering sleeves or straight pins to position the product on the mounting piece.
- ▶ Mount the product on the mounting piece using the appropriate mounting screws.




① Mounting screw

② Straight pins

### 10.2 Installing GED6000IL

The product can be installed from multiple sides.

- ▶ Insert the straight pins or the centering sleeves into the provided fits on the product.
- The type of positioning varies within the series.
- ▶ Use the centering sleeves or straight pins to position the product on the mounting piece.
- ▶ Mount the product on the mounting piece using the appropriate mounting screws.



① Mounting screw

② Straight pins

### 10.3 Safe shutoff for products with IO-Link


#### 10.3.1 Safe shutoff for grippers with IO-Link and without an STO cable

##### INFORMATION



For safe shutoff for products with IO-Link, two contactors are switched in series with one auxiliary contact each. Here, the auxiliary contacts monitor the status of the contactors. If one contactor does not switch, the second contactor ensures safety. The malfunction can still be detected using the contacts.

The following figure shows the example of a circuit through which the IO-Link master cannot conduct the actuator current of the product.



##### NOTICE



Without an externally fed voltage supply, the motor of the product cannot carry out an active movement and thus cannot carry out a hazardous movement. There is no galvanic separation between the two voltage supplies (signal and power). There is a low-voltage connection via the ground (GND). Because of the self-locking mechanism, the product remains in the last approached position, even if no voltage is supplied.




### 10.3.2 Safe shutoff for grippers with IO-Link and with an STO cable

#### INFORMATION



In order to put the gripper into a safe STO status, the STO can be shut off exclusively or together with the power supply. The STO switching unit, e.g. safety PLC or PNOZ, always switches Pin 1 and Pin 4 synchronously (see section "Installing the power supply").



#### INFORMATION



- ▶ Connect the STO signals to the safety relay as follows in order to detect an error in the external switchgear in the form of an electrically conductive bridge:
  - STO\_1 to OSSD\_1
  - STO\_2 to OSSD\_2

#### INFORMATION



The self-locking products come to a stop immediately. Despite a torque-free motor, no more hazardous movements can occur on the product.

### 10.4 Installing the energy supply

#### NOTICE




#### Destruction of the product

In the event that the polarity of the product is reversed, the IO-Link chip may be destroyed as a result of the duration of current of the C/Q (pin 4) being too long.

- ▶ Connect the product according to its assignment diagram.

- ▶ Connect the power supply cable to the control system of the product.



#### 10.4.1 Pin assignment

#### INFORMATION



IO-Link Version 1.1.  
Transmission speed: COM3 (230.4 kBaud).

#### INFORMATION




- ▶ Note the deviation from the IO-Link port class B specification: There is no electrical isolation between the actuator and sensor voltage in the product.
- ⇒ An optional B12 Y-cable allows electrical isolation from the perspective of the IO-Link master.

| Pin | Color | Function       | Explanation                                      | Plug, M12 |
|-----|-------|----------------|--|-----------|
| 1   | Brown | 24 V DC sensor | 24 V DC supply voltage for IO-Link communication |           |
| 2   | White | PWR actuator   | 24 V DC supply voltage for actuator              |           |
| 3   | Blue  | GND sensor     | 0 V DC supply voltage for IO-Link communication  |           |
| 4   | Black | C/Q            | IO-Link communication                            |           |
| 5   | Gray  | GND actuator   | 0 V DC supply voltage for actuator               |           |

- ▶ Connect the product to the IO-Link master.
- ▶ Ensure the proper voltage supply.
- ▶ Configure the IO-Link master (see the chapter "Commissioning").

10.4.2 B12-Y-5IL Y-cable pin assignment



- ① Socket
- ② Plug 1
- ③ Plug 2

| Pin | Color | Function       | Explanation                                      | Socket, M12 |
|-----|-------|----------------|--|-------------|
| 1   | Brown | 24 V DC sensor | 24 V DC supply voltage for IO-Link communication |             |
| 2   | White | PWR actuator   | 24 V DC supply voltage for actuator              |             |
| 3   | Blue  | GND sensor     | 0 V DC supply voltage for IO-Link communication  |             |
| 4   | Black | C/Q            | IO-Link communication                            |             |
| 5   | Gray  | GND actuator   | 0 V DC supply voltage for actuator               |             |
| Pin | Color | Function       | Explanation                                      | Plug 1, M12 |
| 1   | Brown | PWR actuator   | 24 V DC supply voltage for actuator              |             |
| 3   | Blue  | GND actuator   | 0 V DC supply voltage for actuator               |             |
| 4   | Black | -              | -  |             |
| Pin | Color | Function       | Explanation                                      | Plug 2, M12 |
| 1   | Brown | 24 V DC sensor | 24 V DC supply voltage for IO-Link communication |             |
| 3   | Blue  | GND sensor     | 0 V DC supply voltage for IO-Link communication  |             |
| 4   | Black | C/Q            | IO-Link communication                            |             |

### 10.4.3 Pin assignment for products with an STO connection

| Pin | Color | Function             | Explanation                                     | Plug, M8 |
|-----|-------|----------------------|---|----------|
| 1   | Brown | Sensor 24 V DC STO-1 | STO_1 signal from external safety switch device |          |
| 3   | Blue  | GND                  | Ground potential                                |          |
| 4   | Black | 24 V DC STO-2 signal | STO_2 signal from external safety switch device |          |

- ▶ Carry out the listed steps for wiring the product to the IO-Link.
- ▶ Wire the product to the STO line.
- ▶ Connect the STO1 and STO2 signals at the same time using the identical voltage level (0 V or 24 V).
- ⇒ Failure to observe this will result in the product switching to a safe state and signaling = 0x0100 at the diagnostics.
- ⇒ The product cannot be moved any more without a cold boot because a fatal error is present.

### 10.5 Wiring

The product is in a safe state if both STO signals have the status FALSE (0 V). The STO circuit in the product is interrupted.

- ▶ To move the product again, set both STO signals to the status of "TRUE" (24 V).
- ⇒ The diagnostics of the product change to 0x0001 (Motor switched off) if the wiring is correct.
- ▶ Switch on the motor.
- ▶ Select the desired DeviceMode and transfer it.
- ▶ Start the movement.

## 10.6 Static charge

The movement of the gripper jaws creates low voltages as a result of static charging. These charges cannot be dissipated if the product is mounted on an insulating surface and if discharge is also not possible through the workpiece.

### NOTICE





#### Material damage from static charge

ESD-sensitive parts can be damaged if they come into contact with the product.

Grounding the product is also recommended for applications that require high EMC resistance.

- ▶ Ground the product by attaching the cable to the ground connection.



- ① Ground connection
- ② Mounting screw

## 10.7 Heat dissipation

### NOTICE



#### Material damage from overheating of the product

If the product is operated under a very high ambient temperature and with fast clock cycles on an ongoing basis, this can reduce its service life.

- ▶ If the product is exposed to high ambient temperatures, always install it on heat-conducting materials.
- ▶ Reduce the load with increasing temperature.

## 10.8 Installing accessories

### NOTICE



#### Non-compliance may result in material damage.

- ▶ Before installing an accessory, make sure it is suitable for use with the selected variant.
- ▶ You can find information on our website.
- ▶ Please contact Customer Service if you have any questions.

## 11 Commissioning

### CAUTION



**Reduction of the gripping force can cause injury and material damage**

When flexible components are gripped, the gripping force of the product is reduced.

Reduced gripping force can cause injuries or material damage because the components can no longer be securely gripped and transported.

- ▶ Do not stand or walk underneath suspended loads.

### NOTICE




**Malfunction in case of non-compliance**

- ▶ Note the correct setting of the gripping force and the selection of the gripper finger length to prevent the gripper jaws from tensioning.

### 11.1 Process data

There is an option to control the product only with the process data that is transmitted in each cycle.

| Process data output | Data type |
|---------------------|-----------|
| ControlWord         | UINT16    |
| DeviceMode          | UINT8     |
| WorkpieceNo         | UINT8     |
| Reserve             | UINT8     |
| PositionTolerance   | UINT8     |
| GripForce           | UINT8     |
| DriveVelocity       | UINT8     |
| BasePosition        | UINT16    |
| ShiftPosition       | UINT16    |
| TeachPosition       | UINT16    |
| WorkPosition        | UINT16    |



| Process data input | Data type |
|--------------------|-----------|
| StatusWord         | UINT16    |
| Diagnosis          | UINT16    |
| ActualPosition     | UINT16    |

## 11.2 IODD Import

- ▶ Import the IODD (device description) into the control system.
  - ▶ Go to our website.
  - ▶ Select the desired product.
  - ▶ Download the corresponding .zip file via the Downloads section under IODD.
- ⇒ As soon as the hardware configuration is complete and the IO-Link connection to the product is established, data will be displayed in the process input data.
- ⇒ Some control systems demand a byte swap to bring this process data into a logical sequence.
- ▶ Look at bit 6 (GripperPLCActive) in the StatusWord to determine whether a byte swap is necessary.
  - ▶ Determine whether bit 6 is active in the first or second byte of the StatusWord.
    - ⇒ Bit 6 is active in the first byte: The bytes already have the correct sequence.
      - ▶ Continue with the commissioning.
    - ⇒ Bit 6 is active in the second byte:
      - ▶ Apply a byte swap (see the section "StatusWord").

### INFORMATION



The product is controlled via IO-Link by means of the cyclical process data as well as the acyclic service data with a cycle time of 10 ms.

- ▶ You must check the process data.

## 11.3 Handshake Data Transfer Method

The handshake method makes it possible to transfer the process data about the product. All process data described in the following sections must be transferred with the handshake.

- ▶ Send the ControlWord = 0x0001 to the product.
- ⇒ The data transfer was started.
- ▶ Check the response of the product by using StatusWord.12 = TRUE (data transfer OK).
- ▶ Send the ControlWord = 0x0000 to stop the data transfer.
- ⇒ The data transfer is complete when the product sends back StatusWord.12 = DataTransferOK = FALSE.

### INFORMATION



- ▶ For examples, refer to the "Quickstart Basic Parameters" section.

## 11.4 Parameters

### 11.4.1 ControlWord

**NOTICE**



**Malfunction in case of non-compliance**

For ControlWord, only one single bit or the value 0 may be set at a time. Only the values listed in the following table are valid.

| Parameter          | Decimal value | Hexadecimal value |
|--------------------|---------------|-------------------|
| DataTransfer       | 1             | 0x0001            |
| WritePDU           | 2             | 0x0002            |
| ResetDirectionFlag | 4             | 0x0004            |
| Teach              | 8             | 0x0008            |
| MoveToBase         | 256           | 0x0100            |
| MoveToWork         | 512           | 0x0200            |
| JogToWork +        | 1024          | 0x0400            |
| JogToBase -        | 2048          | 0x0800            |

| Name        | ControlWord |
|-------------|-------------|
| Data type   | UINT16      |
| Permission  | Write       |
| Transfer    | Cyclical    |
| Value range | 0 - 65535   |

|               | Bit 15 | Bit 14 | Bit 13 | Bit 12 | Bit 11    | Bit 10             | Bit 9      | Bit 8        |
|---------------|--------|--------|--------|--------|-----------|--------------------|------------|--------------|
| <b>Byte 1</b> | -      | -      | -      | -      | JogToBase | JogToWork          | MoveToWork | MoveToBase   |
|               | Bit 7  | Bit 6  | Bit 5  | Bit 4  | Bit 3     | Bit 2              | Bit 1      | Bit 0        |
| <b>Byte 2</b> | -      | -      | -      | -      | Teach     | ResetDirectionFlag | WritePDU   | DataTransfer |

**Bit 0: DataTransfer**

Setting this bit causes the product to acquire the data transmitted in the process data ("WorkpieceNo" = 0) or the data stored in the workpiece data ("WorkpieceNo" = 1 to 32) as the active data set.

Setting this bit tells the product that the direction flag needs to be reset. This function is available starting from Application Firmware Version SWA000059\_000 (see chapter "Table of acyclic data (ISDU)" Index 0x0017).

**Bit 1: WritePDU**

Setting this bit tells the product that the current process data should be written to the selected tool recipe.

**Bit 2: ResetDirectionFlag**

Setting this bit tells the product that the direction flag needs to be reset. This makes a repeated movement to a position possible. This is logical during a switchover of workpiece recipes.

**NOTICE**



**Material damage from overheating of the product**

▶ Please note that the product can be damaged from overheating due to repeated, prompt movement to the end stop or with a gripped workpiece.

**Bit 3: Teach**

Setting this bit tells the product that the current position should be saved as the TeachPosition in the selected WorkpieceNo. This only works if there is no "0" that is transmitted in the workpiece number.



**Bit 8: MoveToBase**

Setting this bit tells the product to move toward the BasePosition.

**Bit 9: MoveToWork**

Setting this bit tells the product to move toward the WorkPosition.

**Bit 10: JogToWork**

Setting this bit in the ControlWord puts the product in jog mode and slowly moves it toward the WorkPosition. If the bit is reset, the product stops.

**Bit 11: JogToBase**

Setting this bit in the ControlWord puts the product in jog mode and slowly moves it toward the BasePosition. If the bit is reset, the product stops.

**11.4.2 DeviceMode**

The DeviceMode parameter can be used to control the movement of the product and the adaptation to the workpiece. For this purpose, various basic modes and movement profiles are available.

| Name        | DeviceMode |
|-------------|------------|
| Data type   | UINT8      |
| Permission  | Write      |
| Transfer    | Cyclical   |
| Value range | 0 to 255   |

**INFORMATION**



► Note that different operating modes are available depending on the product, (see chapter "Movement profiles for the GEH6xxxIL-03-B/GED6xxxIL-03-A" and "Movement profiles for the GEH6xxxIL-31-B/GED6xxxIL-31-A").

### 11.4.3 Basic commands

These modes control the basic product actions.

| DeviceMode | Action   | ControlWord   |
|------------|--|---------------|
| 0          | Not sent to the motor control system.                    | dc            |
| 1          | Idle   | 0x0001        |
| 2          | Gripper reset  | 0x0001        |
| 3          | Switch on the motor control.                             | 0x0001        |
| 5          | Switch the motor control off/stop the gripping movement. | 0x0001        |
| 11         | Activate jog mode.                                       | 0x0400/0x0800 |

#### 1 Idle

In this mode, no movement can be carried out (idle command).

#### 2 Gripper reset

A reset of the motor controller is triggered in this mode.

#### 3 Switch on the motor control

The motor control is switched on and the output stage is activated. The movement is started after a move command is issued.

#### 5 Switch off the motor control

The motor control is switched off and the output stage is activated. All movements of the product are stopped.

#### 11 Jog operation

The product is in jog mode and moves slowly in the selected direction as long as the respective bit is active in the ControlWord.

Revoking the move command results in an immediate standstill of the product. This mode can be used for setting up the gripper positions.

### 11.4.4 WorkpieceNo

The workpiece number is used for selecting the previously stored workpiece data, as well as for selecting the WorkpieceNo data record in which the current process data is stored.

WorkpieceNo enables individual workpieces to be taught in to the product very quickly if the recipes are not managed on the control system.

With a value > 0 and data acquisition via a handshake, the corresponding workpiece recipe is loaded in the product.

**INFORMATION**



For example codes, refer to the "Quickstart Basic Parameters" and "Recipe Examples" sections.

| Name        | WorkpieceNo |
|-------------|-------------|
| Data type   | UINT8       |
| Permission  | Write       |
| Transfer    | Cyclical    |
| Value range | 0 - 32      |

### 11.4.5 PositionTolerance

Used to configure the position tolerance with a resolution of 0.01 mm.

Thus, the value range of 0 to 255 can be used to set a maximum tolerance of 2.55 mm in both directions.


**INFORMATION**



Example:

For TeachPosition 1500 (15 mm), PositionTolerance 150 lets you configure a tolerance of 1.5 mm in both directions.

This means that the TeachPosition range starts at 13.5 mm and goes all the way up to 16.5 mm.



| Name        | PositionTolerance |
|-------------|-------------------|
| Data type   | UINT8             |
| Permission  | Write             |
| Transfer    | Cyclical          |
| Value range | 0 to 255          |

### 11.4.6 GripForce

The product can use various gripping forces for an optimized process sequence. The gripping force is indicated as a percent from the minimum to the maximum gripping force. The user can transmit the required gripping force in increments of 1%.

| Name        | GripForce  |
|-------------|------------|
| Data type   | UINT8      |
| Permission  | Write      |
| Transfer    | Cyclical   |
| Value range | 1 to 100 % |

#### NOTICE



#### Material damage and malfunction in case of non-compliance

For the products GEH6000IL-03 and GED6000IL-03, operation up to 130% gripping force is possible. During this process, the product switches to a higher maximum permitted peak current.

⇒ Depending on the shape of the gripper fingers, the product may become jammed.

### 11.4.7 DriveVelocity

The product can work at various movement speeds for an optimized process sequence.

This parameter determines the movement speed of the product in both directions in PositionProfile.

In the other modes, this parameter determines the movement speed from the workpiece.

In PrePosition-ForceProfile mode, it determines the movement speed to the switching position.

The positioning speed is specified as a percentage value (1% to 100%). The product converts this information to its maximum movement speed.

#### INFORMATION



Example:

To set a movement speed of 75%, a value of 75 (DriveVelocity = 75) must be transmitted.

| Name        | DriveVelocity |
|-------------|---------------|
| Data type   | UINT8         |
| Permission  | Write         |
| Transfer    | Cyclical      |
| Value range | 1 to 100 %    |

### 11.4.8 BasePosition

The BasePosition defines the target position in the MoveToBase direction. It must always be less than the ShiftPosition.

The product verifies this and, if necessary, displays an error message.

If the current position of the jaws is within the tolerance range in the vicinity of the BasePosition, bit 8 is set in the StatusWord.

Moving beyond this position is also possible.

► Select an appropriately large distance to the mechanical end stop.

| Name        | BasePosition                                     |
|-------------|--|
| Data type   | UINT16   |
| Permission  | Write  |
| Transfer    | Cyclical   |
| Value range | 0.75 to max. jaw stroke of the product + 0.75 mm |

### 11.4.9 ShiftPosition

The ShiftPosition must always be larger than the BasePosition and smaller than the WorkPosition.

The product verifies this and, if necessary, displays an error message.

The input is on a scale of 1/100 mm (Example: 1000 = 10 mm).

| Name        | ShiftPosition                                    |
|-------------|--|
| Data type   | UINT16   |
| Permission  | Write  |
| Transfer    | Cyclical   |
| Value range | 0.75 to max. jaw stroke of the product + 0.75 mm |

### 11.4.10 TeachPosition

The TeachPosition defines the target position of the workpiece and its use is optional.

If the current position of the product within the tolerance range is around the TeachPosition, bit 9 is set in the Status.

The size of the tolerance range is defined with the parameter PositionTolerance.

This is entered at a scale of 1/100 mm (example: 1500 = 15 mm).

| Name        | TeachPosition                                    |
|-------------|--|
| Data type   | UINT16   |
| Permission  | Write  |
| Transfer    | Cyclical   |
| Value range | 0.75 to max. jaw stroke of the product + 0.75 mm |

### 11.4.11 WorkPosition

The WorkPosition defines the maximum travel path of the product and has to be greater than the ShiftPosition.

If the current position of the product is within the tolerance range of the WorkPosition, bit 10 is set in the status.

In the PositionProfile, this position is precisely approached because the product is in positioning mode.

In DeviceMode 60 and 80, the product is stopped, starting from this position. The product moves past the WorkPosition. A maximum of 2 mm, depending on the movement speed and gripper finger dimensions.

| Name        | WorkPosition                                     |
|-------------|--|
| Data type   | UINT16   |
| Permission  | Write  |
| Transfer    | Cyclical   |
| Value range | 0.75 to max. jaw stroke of the product + 0.75 mm |

### 11.4.12 StatusWord

StatusWord structure:

|               | Bit 15 | Bit 14                | Bit 13                | Bit 12               | Bit 11                 | Bit 10       | Bit 9         | Bit 8                  |
|---------------|--------|-----------------------|-----------------------|----------------------|------------------------|--------------|---------------|------------------------|
| <b>Byte 1</b> | Error  | ControlWord<br>0x0200 | ControlWord<br>0x0100 | DataTransferOK       | Undefined-<br>Position | WorkPosition | TeachPosition | BasePosition           |
|               | Bit 7  | Bit 6                 | Bit 5                 | Bit 4                | Bit 3                  | Bit 2        | Bit 1         | Bit 0                  |
| <b>Byte 0</b> | -      | Gripper-<br>PLCActive | JogWork-<br>Active +  | JogBase-<br>Active - | Movement-<br>Complete  | InMotion     | MotorON       | HomingPo-<br>sition OK |

#### Bit 0: HomingPosition OK

The product has its reference. This bit is mandatory. If the reference run is FALSE, a new reference run must be carried out (see the chapter "Referencing by Homing").

#### Bit 1: MotorON

This bit becomes TRUE when the motor is switched on.

#### Bit 2: InMotion

This bit is active during the run.

#### Bit 3: MovementComplete

This bit is active after the movement is complete.

#### Bit 4: JogBaseActive -

Confirmation during the Jog run in the direction of BasePosition.

#### Bit 5: JogWorkActive +

Confirmation during the Jog run in the direction of WorkPosition.

#### Bit 6: GripperPLCActive

Active as soon as the product has booted up after the cold boot. This bit can be used to verify a "byte swap."

#### Bit 8: BasePosition

Active if the product is set to BasePosition.

#### Bit 9: TeachPosition

Active if the product is set to TeachPosition.

#### Bit 10: WorkPosition

Active if the product is set to WorkPosition.

**Bit 11: UndefinedPosition**

Active if the product is not set to TeachPosition, WorkPosition or BasePosition.

**Bit 12: DataTransferOK**

This bit is used for data transmission using the handshake. Active as soon as the product has taken over the data using the parameter ControlWord = 1 (decimal).

**Bit 13: ControlWord 0x0100**

This bit is a direction flag. Active if the last motion task was carried out toward BasePosition.

**Bit 14: ControlWord 0x0200**

This bit is a direction flag. Active if the last motion task was carried out toward WorkPosition.

**Bit 15: Error**

Active if the product has an active error. The error message can be determined using Diagnosis.

**11.4.13 Diagnosis**

The value returned in Diagnosis corresponds to the error code (see "Error Diagnosis" section).

| Name        | Diagnosis |
|-------------|-----------|
| Data type   | UINT16    |
| Permission  | Read      |
| Transfer    | Cyclical  |
| Value range | 0 - 65535 |

**11.4.14 ActualPosition**

ActualPosition is the current position of the gripper jaws.

The value is specified with a resolution of 0.01 mm.

The values can move between the BasePosition (minimum values) and the WorkPosition (maximum values).

With the position measuring system, it is possible to achieve a position accuracy of ± 0.05 mm.

| Name        | ActualPosition                      |
|-------------|-------------------------------------|
| Data type   | UINT16                              |
| Permission  | Read                                |
| Transfer    | Cyclical                            |
| Value range | 0 to max. jaw stroke of the product |

**INFORMATION**



- ▶ Use the StatusWord to check whether a workpiece has been gripped correctly.
- The position measurement resolution is 0.01 mm.
- The position measurement accuracy is 0.1 mm.
- ▶ During commissioning, be aware of fluctuations around the exact value if you use ActualPosition to detect the workpiece.

### 11.5 Cold start

For proper function, Zimmer GmbH recommends that the actuator and sensor voltage be supplied with power separately. The sensor supply must be switched on first.

As soon as the product is communicating with the PLC, the actuator power supply can be switched on. Depending on the application, simultaneous activation of both voltages is also possible.

#### INFORMATION



If the sensor supply is disconnected, the C/Q signal (IO-Link) must be disconnected as well.

### 11.6 Minimum travel path

The product requires a certain minimum travel path to generate the full gripping force when moving to the desired position.

| Design size    | Minimum travel path per gripper jaw [mm] |
|----------------|--|
| GEH6040IL-03-B | 3  |
| GEH6040IL-31-B | 3  |
| GEH6060IL-03-B | 3  |
| GEH6060IL-31-B | 3  |
| GEH6140IL-03-B | 1  |
| GEH6180IL-03-B | 1  |
| GED6040IL-03-A | 4  |
| GED6040IL-31-A | 4  |
| GED6140IL-03-A | 2  |



### 11.7 Referencing by Homing

**INFORMATION**



► Before each homing command, make sure that the product is able to move freely and easily and that it cannot be blocked by the gripper jaws or interfering edges.

When blocking, the reference position is set. A Homing command is not permitted in the gripped state.

There are various Homing commands available.

**INFORMATION**




DeviceModes 16 and 17 are not valid for products with safety gripper jaws!

| DeviceMode | Action   |
|------------|--|
| 10         | Outside homing – to the internal end stop of the product (see "DeviceMode 10" section) |
| 14         | Inside homing – to the internal end stop of the product (see "DeviceMode 14" section)  |
| 16         | Special outside homing – to the external end stop (see "DeviceMode 16" section)        |
| 17         | Special inside homing – to the external end stop (see "DeviceMode 17" section)         |

The product has reached its zero position if the gripper jaws are at the pictured position when referencing (Homing DeviceMode 10).

Depending on installation size, the gripper jaws move slightly beyond the edge of the gripper housing when moving to the home position (Homing).



### 11.7.1 DeviceMode 10

#### WARNING



#### Risk of injury due to uncontrolled movements

Transmitting the value might cause the product to move.

- ▶ Always keep an adequate safety distance.
- ▶ Do not reach into the operational range of the product.

- ▶ Assign "DeviceMode 10.
- ▶ Transmit this value to the product with a handshake.
  - The motor can be switched on or off.
- ⇒ The motor is switched on.
- ⇒ The gripper jaws move to the outside at low speed until they encounter the internal mechanical end stops.
- ⇒ If the gripper jaws encounter resistance, they stop at this spot.
  - ⇒ In the process, the ActualPosition is referenced to the value of 0.

#### INFORMATION



For product variants GEH6xxxIL-31-B and GED6xxxIL-31-A, the position can also take on a value higher than 0 after homing.

### 11.7.2 DeviceMode 14

#### WARNING



#### Risk of injury due to uncontrolled movements

Transmitting the value might cause the product to move.

- ▶ Always keep an adequate safety distance.
- ▶ Do not reach into the operational range of the product.

- ▶ Assign DeviceMode 14.
- ▶ Transmit this value to the product with a handshake.
  - The motor can be switched on or off.
- ⇒ The motor is switched on.
- ⇒ The gripper jaws move to the inside at low speed until they encounter the internal mechanical end stops.
- ⇒ If the gripper jaws encounter resistance, they stop at this spot.
  - ⇒ In the process, the ActualPosition is referenced to the maximum jaw stroke of the product.

#### INFORMATION



For the products of the variants GEH6xxxIL-31-B and GED6xxxIL-31-A, the ActualPosition can be less than the maximum position after homing.

11.7.3 DeviceMode 16

**WARNING**



**Risk of injury due to increased force of the product during homing**

The product force during the reference run is very high with DeviceMode 16.

- ▶ Do not reach into the operational range of the product.
- ▶ Note that if the internal end stop of the product is used, this will result in higher wear.
- ▶ Attach an external end stop to the machine and/or system in which the product is installed.

- ▶ Set the DriveVelocity to a low value before starting homing.
  - Recommendation: DriveVelocity **10**
  - ▶ Increase the value if a higher force is required for homing.
- ▶ Assign DeviceMode 3.
- ▶ Transmit this value to the product with ControlWord 1.
- ⇒ The motor is switched on.
- ▶ Transmit the following values.

| Parameter         | Value      | Unit    |
|-------------------|------------|---------|
| DeviceMode        | 16         | -       |
| WorkpieceNo       | 0          | -       |
| PositionTolerance | 50         | 0.01 mm |
| DriveVelocity     | <b>10</b>  | %       |
| BasePosition      | <b>100</b> | 0.01 mm |
| WorkPosition      | 4000       | 0.01 mm |

- ▶ Transmit the parameters to the product with a handshake.
  - ControlWord 1
  - BasePosition must not be smaller than 75.
- ⇒ The gripper jaws move to the outside until they encounter the internal mechanical end stops.
  - ⇒ After reaching the mechanical end stops, the product accepts the value of the BasePosition for the new ActualPosition.
- ⇒ For example, the new ActualPosition would be 100 (see table).
- ⇒ After homing, the motor is switched off.
  - ▶ Switch the motor on using DeviceMode 3 and the handshake.
  - ▶ Change the movement profile.
  - ▶ Start the operation.
- ⇒ The product responds with DiagnosisWord 0x0000.
  - ⇒ The product is ready.

**WARNING**



**Risk of injury and material damage in case of non-compliance**

Since the ActualPosition in this DeviceMode has an offset, the product does not know the position of the internal end stop. Thus the product with a higher speed can move against the internal end stop.

- ▶ Note that the product can jam or be damaged when moving to the end stop.
- ▶ Make sure that an external end stop is installed in the machine or system into which the product is being installed.

**INFORMATION**



For the product variants GEH6xxxIL-31-B and GED6xxxIL-31-A, the ActualPosition can be greater than the specified BasePosition after homing.

### 11.7.4 DeviceMode 17

#### WARNING



#### Risk of injury due to increased force of the product during homing

The product force during the reference run is very high with DeviceMode 17.

- ▶ Attach an external end stop to the machine and/or system in which the product is installed.
- ▶ Note that if the internal end stop of the product is used, this will result in higher wear.

- ▶ Set the DriveVelocity to a low value before starting homing.
    - Recommendation: DriveVelocity **10**
    - ▶ Increase the value if a higher force is required for homing.
  - ▶ Assign DeviceMode 3.
  - ▶ Transmit this value to the product with ControlWord 1.
- ⇒ The motor is switched on.
- ▶ Transmit the following values.

| Parameter         | Value       | Unit    |
|-------------------|-------------|---------|
| DeviceMode        | 17          | -       |
| WorkpieceNo       | 0           | -       |
| PositionTolerance | 50          | 0.01 mm |
| DriveVelocity     | <b>10</b>   | %       |
| BasePosition      | 100         | 0.01 mm |
| WorkPosition      | <b>4000</b> | 0.01 mm |

- ▶ Transmit the parameters to the product with a handshake.
    - ControlWord 1
    - WorkPosition must not be greater than the maximum position.
- ⇒ The gripper jaws move inward until they are stopped by an external end stop or the maximum jaw position.
- ⇒ The product takes over the WorkPosition value as the new ActualPosition.
- ⇒ For example, this would be the new ActualPosition **4000** (see table).
- ⇒ After homing, the motor is switched off.
- ▶ Switch the motor on using DeviceMode 3 and the handshake.
  - ▶ Change the movement profile.
  - ▶ Start the operation.
- ⇒ The product responds with DiagnosisWord 0x0000.
- ⇒ The product is ready.

#### WARNING



#### Risk of injury and material damage in case of non-compliance

Since the ActualPosition in this DeviceMode has an offset, the product does not know the position of the internal end stop. Thus the product with a higher speed can move against the internal end stop.

- ▶ Note that the product can jam or be damaged when moving to the end stop.
- ▶ Make sure that an external end stop is installed in the machine or system into which the product is being installed.

#### INFORMATION



For the product variants GEH6xxxIL-31-B and GED6xxxIL-31-A, the ActualPosition can be less than the specified WorkPosition after homing.

### 11.8 Movement profiles GEH6xxxIL-03-B/GED6xxxIL-03-A

Various operating modes are available for products with a self-locking mechanism. Zimmer GmbH recommends operating modes 63 and 73 for standard operation.

| DeviceMode | Description  |
|------------|--|
| <b>5x</b>  | <b>Positioning profiles</b>                                |
| 50         | Standard   |
| 51         | High clock rate  |
| <b>6x</b>  | <b>Force profiles – Outside gripping</b>                   |
| 60         | Without holding pressure for energy-saving gripping        |
| 61         | High clock rate for energy-saving gripping                 |
| 63         | With holding pressure for detecting part loss              |
| 64         | With stronger holding pressure for detecting part loss     |
| 65         | Without holding pressure for flexible/elastic components   |
| <b>7x</b>  | <b>Force profiles – Inside gripping</b>                    |
| 70         | Without holding pressure for energy-saving gripping        |
| 71         | High clock rate for energy-saving gripping                 |
| 73         | With holding pressure for detecting part loss              |
| 74         | With stronger holding pressure for detecting part loss     |
| 75         | Without holding pressure for flexible/elastic components   |
| <b>8x</b>  | <b>Pre-positioning – Force profiles – Outside gripping</b> |
| 80         | Without holding pressure for energy-saving gripping        |
| 81         | High clock rate for energy-saving gripping                 |
| 84         | With stronger holding pressure for detecting part loss     |
| 85         | With holding pressure for detecting part loss              |
| <b>9x</b>  | <b>Pre-positioning – Force profiles – Inside gripping</b>  |
| 90         | Without holding pressure for energy-saving gripping        |
| 91         | High clock rate for energy-saving gripping                 |
| 94         | With stronger holding pressure for detecting part loss     |
| 95         | With holding pressure for detecting part loss              |

### 11.8.1 Positioning profiles

Modes 50 and 51 can be used for positioning the jaws or for form-fit gripping.


The movement speed is configured using the DriveVelocity parameter.

The TeachPosition and ShiftPosition parameters do not have any significance in this mode because the BasePosition or WorkPosition is always approached precisely.

If the product encounters an obstacle in this mode, the movement stops.

The product can be moved from the obstacle back to the starting position if the command is switched in the ControlWord.

No defined gripping forces can be generated in this mode. As a result, friction-locked gripping is not permitted in this mode.



| DeviceMode | Action   | ControlWord   |
|------------|--|---------------|
| 50         | Positioning to BasePosition or WorkPosition                                | 0x0100/0x0200 |
| 51         | Positioning without an unlocking operation to BasePosition or WorkPosition | 0x0100/0x0200 |

#### Positioning profile 50: Standard

The move commands in the ControlWord trigger a movement in the corresponding direction at the selected DriveVelocity.

#### Positioning profile 51: High clock rate

Behaves like mode 50, but when the gripping movement starts, the unlocking operation is omitted. This enables a shorter response time.

- ▶ Ensure that no gripping force is acting on the gripper jaws.
- ⇒ The movement may stop as a result.

### 11.8.2 Force profiles

Mode Groups 60 and 70 can be used for form-fit gripping.

The gripping force is built up by the movement speed of the product and the motor current. The product automatically calculates the required GripVelocity from the GripForce parameter.


When gripping a workpiece, a mechanical locking system is triggered that makes it possible to hold the workpiece de-energized. To release the locking system, an unlocking operation must be carried out.

To unlock, the product must be moved toward the standby position at DriveVelocity. The product then switches into positioning mode.


The figure shows outside gripping using Mode Group 60 as an example. For Mode Group 70, the BasePosition and the WorkPosition are exchanged.

The figure shows outside gripping using Mode Group 60 as an example. For Mode Group 70, the BasePosition and the WorkPosition are exchanged.

#### Gripping in the direction of WorkPosition



#### Opening



| Parameter         | Description                           |
|-------------------|---------------------------------------|
| BasePosition      | Open position                         |
| WorkPosition      | Closed position                       |
| GripForce         | Desired gripping force                |
| TeachPosition     | Expected position of the workpiece    |
| PositionTolerance | Permitted tolerance for the workpiece |
| DriveVelocity     | Opening speed                         |
| ShiftPosition     | Not used                              |

The movement profile determines the direction in which the workpiece is gripped:

- Outside gripping: Movement profile group 60
- Inside gripping: Movement profile group 70


### 11.8.2.1 Force profiles group 60 – Outside gripping

In Mode Group 60, the product moves in the ForceProfile from the BasePosition toward the WorkPosition onto the workpiece with ControlWord 0x0200.

The workpiece is gripped and the set gripping force is built up. The self-locking mechanism is activated automatically. For releasing, an unlocking operation must be carried out.

If no workpiece is gripped during the gripping process, the product moves on to the WorkPosition and is braked. The product moves behind the configured position before it turns around and comes to a stop at the WorkPosition. This enables secure gripping of workpieces up to the WorkPosition.

The ControlWord 0x0100 is used to open the product. The product is moved automatically to the BasePosition in the PositionProfile.



| DeviceMode | Action   | ControlWord |
|------------|--|-------------|
| 6x         | Move toward the BasePosition to open the product.  | 0x0100      |
| 60         | Move toward the WorkPosition until this position or the workpiece is reached.  | 0x0200      |
| 61         | Move toward the WorkPosition until this position or the workpiece is reached. Do not carry out an unlocking process.                             | 0x0200      |
| 63         | Move toward the WorkPosition until this position or the workpiece is reached. Carry out test for part loss.                                      | 0x0200      |
| 64         | Move toward the WorkPosition until this position or the workpiece is reached. Carry out test for part loss with stronger holding pressure force. | 0x0200      |
| 65         | Move toward the WorkPosition until this position or the workpiece is reached. Move at a reduced speed.   | 0x0200      |

#### Force profile 60: Without holding pressure for energy-saving gripping

Before the movement starts, an unlocking operation is run for releasing. Then, the gripper jaws start moving toward the workpiece. If the gripper jaws encounter the workpiece while moving, an increase in current is detected and the gripping force is built up. The self-locking mechanism is triggered automatically and the motor is practically de-energized.

If the workpiece disengages from the gripper, the gripper jaws do not follow along and no part loss can be detected.

This mode is the recommended energy saving mode.

#### Force profile 61: High clock rate for energy-saving gripping

Behaves like mode 60, but when the gripping movement starts, the unlocking operation is omitted and the movement is started immediately. This enables a shorter response time during the drive to the WorkPosition.

► Ensure that in the BasePosition, no external forces act on the gripper jaws.

#### Force profile 63: With holding pressure for detecting part loss

Behaves like force profile 60, but in this mode, the motor is energized continuously after gripping the workpiece. After the gripping process, the TeachPosition bit is TRUE. In case a part is lost, this causes the machine to move on to the WorkPosition. The part loss can be detected by sensing the WorkPosition.

This mode is the recommended standard operating mode.

#### Force profile 64: With stronger holding pressure for detection of part loss

Behaves like force profile 63, but the motor is energized with more current. This increases the holding pressure force, but the heating of the gripper and the energy consumption increase.

#### Force profile 65: Without holding pressure for flexible/elastic components

Behaves like force profile 60, but the product has a slower movement speed because the majority of the gripping force is created directly by the motor current. It will no longer be possible to generate the full nominal force in the movement because of the lower kinetic energy. The gripping force generated depends on the elasticity of the workpiece.

This mode is the recommended mode for flexible/elastic workpieces.




**11.8.2.2 Force profiles group 70 – Inside gripping**

In Mode Group 70, the product in the ForceProfile moves from the BasePosition toward the WorkPosition onto the workpiece with ControlWord 0x0100.

The workpiece is gripped and the set gripping force is built up. The self-locking mechanism is activated automatically. For releasing, an unlocking operation must be carried out.

If no workpiece is gripped during the gripping process, the product moves on to the WorkPosition and is then braked. The product moves behind the configured position before it turns around and comes to a stop at the BasePosition. This enables secure gripping of workpieces up to the BasePosition.

The ControlWord 0x0200 is used to open the product. The product is moved automatically to the WorkPosition in the PositionProfile.



| DeviceMode | Action   | ControlWord |
|------------|--|-------------|
| 7x         | Move toward the WorkPosition for opening the product.  | 0x0200      |
| 70         | Move toward the BasePosition until this position or the workpiece is reached.  | 0x0100      |
| 71         | Move toward the BasePosition until this position or the workpiece is reached. Do not carry out an unlocking process.                             | 0x0100      |
| 73         | Move toward the BasePosition until this position or the workpiece is reached. Carry out test for part loss.                                      | 0x0100      |
| 74         | Move toward the BasePosition until this position or the workpiece is reached. Carry out test for part loss with stronger holding pressure force. | 0x0100      |
| 75         | Move toward the BasePosition until this position or the workpiece is reached. Move at a reduced speed.   | 0x0100      |

**Force profile 70: Without holding pressure for energy-saving gripping**

When the movement starts, an unlocking operation is run for releasing. Then, the gripper jaws start moving toward the workpiece. If the gripper jaws encounter the workpiece while moving, an increase in current is detected and the gripping force is built up. The self-locking mechanism is triggered automatically and the motor is practically de-energized.

If the workpiece disengages from the gripper, the gripper jaws do not follow along and no part loss can be detected.

⇒ This mode is the recommended energy saving mode.

**Force profile 71: High clock rate for energy-saving gripping**

Behaves like mode 70, but when the gripping movement starts, the unlocking operation is omitted and the movement is started immediately. This enables a shorter response time during the drive to the BasePosition.

► Ensure that in the WorkPosition, no external forces act on the gripper jaws.

**Force profile 73: With holding pressure for detecting part loss**

Behaves like force profile 70, but in this mode, the motor is also energized continuously after gripping the workpiece. After the gripping process, the TeachPosition bit is TRUE. In case a part is lost, this causes the machine to move on to the BasePosition. The part loss can be detected by sensing the BasePosition.

⇒ This mode is the recommended standard operating mode.

**Force profile 74: With stronger holding pressure for detection of part loss**

Behaves like force profile 73, but the motor is energized with more current. This increases the holding pressure force, but the heating of the gripper and the energy consumption also increase.

**Force profile 75: Without holding pressure for flexible/elastic components**

Behaves like force profile 70, but the product has a slower movement speed because the majority of the gripping force is created directly by the motor current. It will no longer be possible to generate the full nominal force in the movement because of the lower kinetic energy. The gripping force generated depends on the elasticity of the workpiece.

⇒ This mode is the recommended mode for flexible/elastic workpieces.

### 11.8.2.3 Pre-positioning force profiles

For Mode Groups 80 and 90, pre-positioning is used. Therefore, these groups are particularly suitable for time-optimized gripping with long strokes followed by force-fit gripping.

The gripping force is built up by the movement speed of the product and the motor current. The product automatically calculates the required GripVelocity from the GripForce parameter.


When gripping a workpiece, a mechanical locking system is triggered that makes it possible to hold the workpiece de-energized. To release the locking system, an unlocking operation must be carried out.

To unlock, the product must be moved toward the standby position at DriveVelocity. The product then switches into positioning mode.


The figure shows outside gripping using Mode Group 80 as an example. For Mode Group 90, the BasePosition and the WorkPosition are exchanged.

The figure shows outside gripping using Mode Group 80 as an example. For Mode Group 90, the BasePosition and the WorkPosition are exchanged.

#### Gripping in the direction of WorkPosition



#### Opening



| Parameter         | Description                            |
|-------------------|--|
| BasePosition      | Open position                          |
| WorkPosition      | Closed position – behind the workpiece |
| GripForce         | Desired gripping force                 |
| TeachPosition     | Expected position of the workpiece     |
| PositionTolerance | Permitted tolerance for the workpiece  |

Since gripping should occur in one direction only, the positioning mode is used automatically in the opposite direction. The movement profile determines the direction in which the workpiece is gripped:

- Outside gripping: Movement profile group 80
- Inside gripping: Movement profile group 90


**11.8.2.4 Pre-positioning force profiles group 80 – Outside gripping**

In Mode Group 80, the product moves with ControlWord 0x0200 in the PositionProfile and to the ShiftPosition with the selected DriveVelocity. Then, the product moves in ForceProfile and with the selected GripForce from the ShiftPosition to the WorkPosition onto the workpiece.

The workpiece is gripped and the set gripping force is built up. The self-locking mechanism is activated automatically. For releasing, an unlocking operation must be carried out.

If no workpiece is gripped during the gripping process, the product moves on to the WorkPosition and is braked. The product moves behind the configured position before it turns around and comes to a stop at the WorkPosition. This enables secure gripping of workpieces up to the WorkPosition.

The ControlWord 0x0100 is used to open the product. The product is moved automatically to the BasePosition in the PositionProfile.



| DeviceMode | Action  | ControlWord |
|------------|---|-------------|
| 8x         | Move toward the BasePosition to open the product.   | 0x0100      |
| 80         | Move in the direction of the WorkPosition at DriveVelocity until the ShiftPosition is reached. Switch to GripForce until the WorkPosition or the workpiece is reached.  | 0x0200      |
| 81         | Move in the direction of the WorkPosition at DriveVelocity until the ShiftPosition is reached. Switch to GripForce until the WorkPosition or the workpiece is reached. Do not carry out an unlocking process. | 0x0200      |
| 84         | Move toward the WorkPosition until this position or the workpiece is reached. Carry out test for part loss with stronger holding pressure force.  | 0x0200      |
| 85         | Move toward the WorkPosition until this position or the workpiece is reached. Carry out test for part loss.   | 0x0200      |

**Pre-positioning force profile 80: Without holding pressure for energy-saving gripping**

Before the movement starts, an unlocking operation is run for releasing. The movement begins with the positioning to the ShiftPosition. The gripper moves at the speed set in the Drive Velocity parameter. Then, the product starts moving toward the workpiece with GripForce. If the product encounters the workpiece while moving, an increase in current is detected and the gripping force is built up. The self-locking mechanism is triggered automatically and the motor is practically de-energized. This enables energy-saving gripping.

If the workpiece disengages from the gripper, the gripper jaws do not follow along and no part loss can be detected.

**Pre-positioning force profile 81: High clock rate for energy-saving gripping**

Behaves like mode 80, but when the gripping movement starts, the unlocking operation is omitted and the movement is started immediately. This enables a shorter response time during the drive to the WorkPosition.

- Ensure that no forces act on the gripper jaws in the BasePosition.

**Pre-positioning force profile 84: With stronger holding pressure for detection of part loss**

Behaves like force profile 85, but the motor is energized with more current. This increases the holding pressure force, but the heating of the gripper and the energy consumption increase.

**Pre-positioning force profile 85: With holding pressure for detecting part loss**

Behaves like force profile 80, but in this mode, the motor is energized continuously after gripping the workpiece. If the gripping process was successful, the bit in the TeachPosition becomes TRUE. In case a part is lost, the product keeps moving to the WorkPosition. The part loss can be detected by sensing the WorkPosition.


**11.8.2.5 Pre-positioning force profiles group 90 – Inside gripping**

In Mode Group 90, the product moves with ControlWord 0x0100 in the PositionProfile to the ShiftPosition with the selected DriveVelocity. Then, the product moves in the ForceProfile with the selected GripForce from the ShiftPosition to the WorkPosition onto the workpiece.

The workpiece is gripped and the set gripping force is built up. The self-locking mechanism is activated automatically. For releasing, an unlocking operation must be carried out.

If no workpiece is gripped during the gripping process, the product moves on to the WorkPosition and is then braked. The product moves behind the configured position before it turns around and comes to a stop at the BasePosition. This enables secure gripping of workpieces up to the BasePosition.

The ControlWord 0x0200 is used to open the product. The product is moved automatically to the WorkPosition in the PositionProfile.



| DeviceMode | Action  | ControlWord |
|------------|---|-------------|
| 9x         | Move toward the WorkPosition for opening the product.   | 0x0200      |
| 90         | Move in the direction of the BasePosition at DriveVelocity until the ShiftPosition is reached. Switch to GripForce until the BasePosition or the workpiece is reached.  | 0x0100      |
| 91         | Move in the direction of the BasePosition at DriveVelocity until the ShiftPosition is reached. Switch to GripForce until the BasePosition or the workpiece is reached. Do not carry out an unlocking process. | 0x0100      |
| 94         | Move toward the BasePosition until this position or the workpiece is reached. Carry out test for part loss with stronger holding pressure force.  | 0x0100      |
| 95         | Move toward the BasePosition until this position or the workpiece is reached. Carry out test for part loss.   | 0x0100      |

**Pre-positioning force profile 90: Without holding pressure for energy-saving gripping**

Before the movement starts, an unlocking operation is run for releasing. The movement begins with the positioning to the ShiftPosition. The gripper moves at the speed set in the Drive Velocity parameter. Then, the product starts moving toward the workpiece with GripForce. If the product encounters the workpiece while moving, an increase in current is detected and the gripping force is built up. The self-locking mechanism is triggered automatically and the motor is practically de-energized. This enables energy-saving gripping.

If the workpiece disengages from the gripper, the gripper jaws do not follow along and no part loss can be detected.

**Pre-positioning force profile 91: High clock rate for energy-saving gripping**

Behaves like mode 90, but when the gripping movement starts, the unlocking operation is omitted and the movement is started immediately. This enables a shorter response time during the drive to the WorkPosition.

- Ensure that in the WorkPosition, no forces act on the gripper jaws.

**Pre-positioning force profile 94: With stronger holding pressure for detection of part loss**

Behaves like force profile 93, but the motor is energized with more current. This increases the holding pressure force, but the heating of the gripper and the energy consumption increase.

**Pre-positioning force profile 95: With holding pressure for detecting part loss**

Behaves like force profile 90, but in this mode, the motor is energized continuously after gripping the workpiece. After the gripping process, the bit in the TeachPosition is TRUE. In case a part is lost, the product moves to the BasePosition. The part loss can be detected by sensing the BasePosition.

### 11.9 Movement profiles GEH6xxxIL-31-B/GED6xxxIL-31-A

Various operating modes are available for products without a self-locking mechanism.

#### 11.9.1 DeviceModes

| DeviceMode | Description  |
|------------|--|
| <b>5x</b>  | <b>Positioning profiles</b>                                |
| 50         | Standard   |
| 51         | High clock rate  |
| <b>6x</b>  | <b>Force profiles – Outside gripping</b>                   |
| 62         | Standard without self-locking mechanism                    |
| <b>7x</b>  | <b>Force profiles – Inside gripping</b>                    |
| 72         | Standard without self-locking mechanism                    |
| <b>8x</b>  | <b>Pre-positioning – Force profiles – Outside gripping</b> |
| 82         | Force profile without self-locking mechanism               |
| <b>9x</b>  | <b>Pre-positioning – Force profiles – Inside gripping</b>  |
| 92         | Force profile without self-locking mechanism               |

#### INFORMATION



Products without a self-locking mechanism exert lower gripping forces due to the increased movement speed. There is no gripping force retention from a self-locking mechanism. The motor is energized continuously during the gripping process. If the workpiece gets lost, the gripping movement is continued to the target position.

### 11.9.2 Positioning profiles

Modes 50 and 51 can be used for positioning the jaws or for form-fit gripping.


The movement speed is configured using the DriveVelocity parameter.

The TeachPosition and ShiftPosition parameters do not have any significance in this mode because the BasePosition or WorkPosition is always approached precisely.

If the product encounters an obstacle in this mode, the movement stops.

The product can be moved from the obstacle back to the starting position if the command is switched in the ControlWord.

No defined gripping forces can be generated in this mode. As a result, friction-locked gripping is not permitted in this mode.



| DeviceMode | Action   | ControlWord   |
|------------|--|---------------|
| 50         | Positioning to BasePosition or WorkPosition                                | 0x0100/0x0200 |
| 51         | Positioning without an unlocking operation to BasePosition or WorkPosition | 0x0100/0x0200 |

#### Positioning profile 50: Standard

The move commands in the ControlWord trigger a movement in the corresponding direction at the selected DriveVelocity.

#### Positioning profile 51: High clock rate

Behaves like mode 50, but when the gripping movement starts, the unlocking operation is omitted. This enables a shorter response time.

- ▶ Ensure that no gripping force is acting on the gripper jaws.
- ⇒ The movement may stop as a result.

### 11.9.3 Force profiles


Mode Groups 60 and 70 can be used for form-fit gripping.

The gripping force is built up by the movement speed of the product and the motor current. The product automatically calculates the required GripVelocity from the GripForce parameter.


For opening, the product moves toward the standby position at DriveVelocity. The product switches into positioning mode automatically.

The figure shows outside gripping using Mode Group 60 as an example. For Mode Group 70, the BasePosition and the WorkPosition are exchanged.

#### Gripping in the direction of WorkPosition



#### Opening



| Parameter         | Description                           |
|-------------------|---------------------------------------|
| BasePosition      | Open position                         |
| WorkPosition      | Closed position                       |
| GripForce         | Desired gripping force                |
| TeachPosition     | Expected position of the workpiece    |
| PositionTolerance | Permitted tolerance for the workpiece |
| DriveVelocity     | Opening speed                         |
| ShiftPosition     | Not used                              |

Since gripping should occur in one direction only, the positioning mode is used automatically in the opposite direction. When opening, the product switches into positioning mode automatically.

The movement profile determines the direction in which the workpiece is gripped:

- Outside gripping: Movement profile group 60
- Inside gripping: Movement profile group 70


### 11.9.3.1 Force profiles group 60 – Outside gripping

In Mode Group 60, the product moves in the ForceProfile from the BasePosition toward the WorkPosition onto the workpiece with ControlWord 0x0200.

The workpiece is gripped; the configured gripping force is built up and maintained by the motor current.

If no workpiece is gripped during the gripping process, the product moves on to the WorkPosition and is braked. The product moves behind the configured position before it turns around and comes to a stop at the WorkPosition. This enables secure gripping of workpieces up to the WorkPosition.

The ControlWord 0x0100 is used to open the product. The product is moved automatically to the BasePosition in the PositionProfile.



#### Mode Group 60 – typically used for outside gripping

| DeviceMode | Action   | ControlWord |
|------------|--|-------------|
| 62         | Move toward the BasePosition to open the product.  | 0x0100      |
| 62         | Move toward the WorkPosition until this position or the workpiece is reached. Do not carry out an unlocking process. | 0x0200      |

#### Force profile 62: Standard without self-locking mechanism

The product moves onto the workpiece. When the product grips the workpiece, the configured gripping force is built up and maintained by the motor current.




### 11.9.3.2 Force profiles group 70 – Inside gripping

In Mode Group 70, the product in the ForceProfile moves from the BasePosition toward the WorkPosition onto the workpiece with ControlWord 0x0100.

The workpiece is gripped; the configured gripping force is built up and maintained by the motor current.

If no workpiece is gripped during the gripping process, the product moves on to the WorkPosition and is then braked. The product moves behind the configured position before it turns around and comes to a stop at the BasePosition. This enables secure gripping of workpieces up to the BasePosition.

The ControlWord 0x0200 is used to open the product. The product is moved automatically to the WorkPosition in the PositionProfile.



#### Mode Group 70 – typically used for inside gripping

| DeviceMode | Action  | ControlWord |
|------------|---|-------------|
| 72         | Move toward the WorkPosition for opening the product.                         | 0x0200      |
| 72         | Move toward the BasePosition until this position or the workpiece is reached. | 0x0100      |

#### Force profile 72: Standard without self-locking mechanism

The product moves onto the workpiece. When the product grips the workpiece, the configured gripping force is built up and maintained by the motor current.

### 11.9.3.3 Pre-positioning force profiles


For Mode Groups 80 and 90, pre-positioning is used. Therefore, these groups are particularly suitable for time-optimized gripping with long strokes followed by force-fit gripping.

The gripping force is built up by the movement speed of the product and the motor current. The product automatically calculates the required GripVelocity from the GripForce parameter.


For opening, the product moves toward the standby position at DriveVelocity. The product switches into positioning mode automatically.

The figure shows outside gripping using Mode Group 80 as an example. For Mode Group 90, the BasePosition and the WorkPosition are exchanged.

#### Gripping in the direction of WorkPosition



#### Opening



| Parameter         | Description                            |
|-------------------|--|
| BasePosition      | Position open                          |
| ShiftPosition     | Switching from positioning to gripping |
| WorkPosition      | Position closed                        |
| GripForce         | Desired gripping force                 |
| TeachPosition     | Expected position of the workpiece     |
| PositionTolerance | Permitted tolerance for the workpiece  |
| DriveVelocity     | Opening speed                          |

Since gripping should occur in one direction only, the positioning mode is used automatically in the opposite direction. The movement profile determines the direction in which the workpiece is gripped:

- Outside gripping: Movement profile group 80
- Inside gripping: Movement profile group 90


**11.9.3.4 Pre-positioning force profiles group 80 – Outside gripping**

In Mode Group 80, the product moves with ControlWord 0x0200 in the PositionProfile and to the ShiftPosition with the selected DriveVelocity. Then, the product moves in ForceProfile and with the selected GripForce from the ShiftPosition to the WorkPosition onto the workpiece.

The workpiece is gripped; the configured gripping force is built up and maintained by the motor current.

If no workpiece is gripped during the gripping process, the product moves on to the WorkPosition and is braked. The product moves behind the configured position before it turns around and comes to a stop at the WorkPosition. This enables secure gripping of workpieces up to the WorkPosition.

The ControlWord 0x0100 is used to open the product. The product is moved automatically to the BasePosition in the PositionProfile.



**Mode Group 82 – typically used for outside gripping**

| DeviceMode | Action   | ControlWord |
|------------|--|-------------|
| 82         | Move toward the BasePosition to open the product.  | 0x0100      |
| 82         | Move to ShiftPosition at DriveVelocity, then switch to GripForce until the WorkPosition or the workpiece is reached. | 0x0200      |

**Pre-positioning force profile 82: Standard**

The movement starts from the BasePosition and begins with the positioning to the ShiftPosition. Here, the product moves at the speed set in the DriveVelocity parameter. Then, the product starts moving toward the workpiece with GripForce. If the product encounters the workpiece while moving, an increase in current is detected and the gripping force is built up. The gripping force is maintained by the motor current.


**11.9.3.5 Pre-positioning force profiles group 90 – Inside gripping**

In Mode Group 90, the product moves with ControlWord 0x0100 in the PositionProfile to the ShiftPosition with the selected DriveVelocity. Then, the product moves in the ForceProfile with the selected GripForce from the ShiftPosition to the WorkPosition onto the workpiece.

The workpiece is gripped; the configured gripping force is built up and maintained by the motor current.

If no workpiece is gripped during the gripping process, the product moves on to the WorkPosition and is then braked. The product moves behind the configured position before it turns around and comes to a stop at the BasePosition. This enables secure gripping of workpieces up to the BasePosition.

The ControlWord 0x0200 is used to open the product. The product is moved automatically to the WorkPosition in the PositionProfile.



**Mode Group 92 – typically used for inside gripping**

| DeviceMode | Action   | ControlWord |
|------------|--|-------------|
| 92         | Move toward the WorkPosition for opening the product.  | 0x0200      |
| 92         | Move to ShiftPosition at DriveVelocity, then switch to GripForce until the BasePosition or the workpiece is reached. | 0x0100      |

**Pre-positioning force profile 90: Standard**

The movement starts from the WorkPosition and begins with the positioning to the ShiftPosition. The gripper moves at the speed set in the Drive Velocity parameter. Then, the product starts moving toward the workpiece with GripForce. If the product encounters the workpiece while moving, an increase in current is detected and the gripping force is built up. The set gripping force is maintained by the motor current.

### 11.10 Interrupting the voltage supply

#### INFORMATION



Switching off the power supply can cause smaller movements of the product. These can add up over time to more severe positioning errors.

During an interruption of the voltage supply (e.g. when using a tool changer), make absolutely sure that the product stores the last position in the controller.

- ▶ Carry out a handshake before switching off the power supply.
- ⇒ This ensures that no change of position occurs during a restart.

The following example code shows the sequence in case the power supply is interrupted.

```
// Interruption of the power supply
// Switching off the motor
CASE iStep OF
0:
    DeviceMode      := 5;      // Motor off
    ControlWord     := 1;      // Start handshake (DataTransfer bit =TRUE in the ControlWord)
    iStep           := 10;     // Jump to the next step

10:
    IF StatusWord.12 AND NOT StatusWord.1 // Queries the bit DataTransferOK=TRUE from StatusWord,
    THEN // Response of the product to transferred data
        ControlWord     := 0; // Reset the ControlWord
        iStep           := 20; // Jump to the next step
    END_IF;

20:
    IF NOT StatusWord.12 THEN
        // Voltage supply can be interrupted
    END_IF
```

### 11.11 Easy Startup

Describes the process from switching on the product to the initial movement.

- ▶ Connect the product according to its assignment diagram.
- ⇒ The product reports the process parameters StatusWord, Diagnosis and ActualPosition immediately after the internal controller is booted up.
- ⇒ As soon as the PLCActive bit is registered in the StatusWord, the communication process can start.
- ▶ Transmit the process parameters to move the product.
  - DeviceMode
  - WorkpieceNo
  - PositionTolerance
  - GripForce
  - DriveVelocity
  - BasePosition
  - ShiftPosition
  - TeachPosition
  - WorkPosition
- ▶ Transmit the parameters to the product with a handshake.

**INFORMATION**

- ▶ For information and an example code for the handshake, refer to the "Quickstart Basic Parameters" and "Recipe Examples" sections.

**11.12 Starting the data transfer**

- ▶ Start the data transmission with the ControlWord = 1 (decimal).
- ⇒ As soon as the process parameter has been transmitted to the product, the product will report this back in the StatusWord with the DataTransferOK bit.
- ⇒ The product is ready to operate.

**INFORMATION**

- ▶ For information about data transfers, refer to the "StatusWord" section.

### 11.13 Quickstart Basic Parameters

#### INFORMATION



The following example code applies to the products GEH6xxxIL-03-B and GED6xxxIL-03-A with a self-locking mechanism.

For products without a self-locking mechanism, Mode Group 82 must be used for operation.

In the following example, you see the first initialization of the product, the activation of the motor and the transmission of the process parameters.

```
// Initialization of the product
// Motor switch-on
// Initial move command
// = EasyStartUp Example
CASE iStep OF
0:
    IF StatusWord.6 and Diag != 0x100 THEN // Query for PLCActive bit in the StatusWord
        ControlWord      := 1; // Data transfer to the product
        DeviceMode        := 3; // Command to switch on the motor
        WorkpieceNo       := 0; // 0 = current process parameters are being used
        PositionTolerance := 50;
        GripForce         := 50;
        DriveVelocity     := 50;
        BasePosition      := 100;
        ShiftPosition     := 2000;
        TeachPosition     := 3800;
        WorkPosition      := 4000;
        iStep             := 10; // Jump to the next step
    END_IF
10:
    IF StatusWord.12 AND StatusWord.1 THEN // Query for DataTransferOK bit AND MotorON in the StatusWord
        ControlWord      := 0; // Reset of the initialization
        iStep            := 20; // Jump to the next step
    END_IF
20:
    IF NOT StatusWord.12 THEN // Query for completion of the data transfer,
        // DataTransferOK = FALSE
        DeviceMode       := 85; // Loading a DeviceMode
        ControlWord      := 1; // Begins with the handshake
        iStep            := 30; // Jump to the next step
    END_IF
30:
    IF StatusWord.12 THEN // Queries the bit DataTransferOK=TRUE from StatusWord,
        // Response of the product to transferred data
        ControlWord      := 0; // Reset the ControlWord
        iStep            := 40; // Jump to the next step
    END_IF;
40:
    IF NOT StatusWord.12 THEN // Query for completion of the data transfer,
        // DataTransferOK = FALSE
        ControlWord      := 512; // Handshake is completed,
        // Product moves to WorkPosition (0x0200 or 512(decimal) = MoveToWork)
        iStep            := 50; // Jump to the next step
    END_IF
50:
    IF NOT StatusWord.10 THEN // Query for reaching the WorkPosition
        ControlWord      := 256; // Set move command toward BasePosition
        iStep            := 60;
    END_IF;
END_CASE
```

### 11.14 Starting the gripping movement

- ▶ Send ControlWord 0x0200 so that the product moves towards the WorkPosition.
- ⇒ The gripper jaws move towards the inside.
- ▶ Send ControlWord 0x0100 so that the product moves towards the BasePosition.
- ⇒ The gripper jaws move towards the outside.
  - The motion task must be pending for as long as it takes until the desired position is reached.
  - The current motion task is canceled as a result of a new handshake.
- ⇒ When the product reaches the corresponding position, this is displayed in the StatusWord as follows:
  - The product is at the BasePosition: StatusWord.8 = TRUE
  - The product is at the TeachPosition: StatusWord.9 = TRUE
  - The product is at the WorkPosition: StatusWord.10 = TRUE
  - The product is not at any of the listed positions: StatusWord.11 = TRUE

### 11.15 Repeated movements in the same direction

The StatusWord includes two static flag bits, each of which is set in alternation when the product moves in one direction. This prevents uncontrolled movements of the product in case of faulty data transmission.

Depending on the location of the positions, it is possible that the product may move multiple times in the same direction. For this purpose, the direction flags must be reset.

- ▶ Send the ControlWord = 0x0004 to delete the direction flags.
- ⇒ The direction flags are reset when the product answers with StatusWord.13 AND 14 = FALSE.

Program example for repeated movements in the same direction:

```
// Multiple movement in one direction in Structured Text (ST)
// In this example, the motor is switched on,
// The movement profile
// Transfer gripping forces and speeds
// The product is at BasePosition = 1000.
CASE iStep OF
10:
    BasePosition      := 100;    // Assignment of a new BasePosition
    ControlWord       := 1;      // Start handshake (DataTransfer bit =TRUE in the ControlWord)
    iStep              := 20;    // Jump to the next step
END_IF;
20:
    IF StatusWord.12 THEN          // Queries the bit DataTransferOK=TRUE from StatusWord,
                                  // Response of the product to transferred data
        ControlWord       := 0;    // Reset the ControlWord
        iStep              := 30;    // Jump to the next step
    END_IF;
30:
    IF NOT StatusWord.12 THEN      // Query for completion of the data transfer,
                                  // DataTransferOK = FALSE
        ControlWord       := 4;    // Reset direction flag
                                  // (DataTransfer bit =TRUE in the ControlWord)
        iStep              := 40;
    END_IF
40:
    IF NOT StatusWord.13 AND NOT   // Query whether both direction flags
    StatusWord.14 THEN             // (Bit ControlWord 0x0100 AND
                                  // ControlWord 0x0200 = FALSE in ControlWord)
        ControlWord       := 256;  // Moves back toward BasePosition
        iStep              := 50;
    END_IF;
END_CASE
```



## 11.16 Recipe examples

### 11.16.1 Save recipe

#### INFORMATION



The following example code applies to the products GEH6xxxIL-03-B and GED6xxxIL-03-A with a self-locking mechanism.

For products without a self-locking mechanism, Mode Group 82 must be used for operation.

The following example code shows how process parameters can be stored in the internal workpiece recipe.

CASE iStep OF

10:

```
IF StatusWord.6 and Diag != 0x100 THEN
    DeviceMode      := 85;    // Assignment of desired process parameters
    WorkpieceNo     := 3;    // Recipe is to be stored as the third workpiece recipe
    PositionTolerance := 50;
    GripForce       := 50;
    DriveVelocity   := 50;
    BasePosition    := 100;
    ShiftPosition   := 2000;
    TeachPosition   := 3800;
    WorkPosition    := 4000;
    iStep           := 20;    // Jump to the next step
```

END\_IF;

20:

```
ControlWord := 1;    // Begins with the handshake
iStep       := 30;    // Jump to the next step
```

30:

```
IF StatusWord.12 THEN // Queries the bit DataTransferOK=TRUE from StatusWord,
                    // Response of the product to transferred data
    ControlWord := 0; // Reset the ControlWord
    iStep       := 40; // Jump to the next step
```

END\_IF;

40:

```
IF NOT StatusWord.12 THEN // Query for completion of the data transfer,
                        // DataTransferOK = FALSE
    ControlWord := 2; // Handshake is completed,
                    // storage starts here via the WritePDU bit in the ControlWord
    iStep       := 50; // Jump to the next step
```

END\_IF;

50:

```
IF StatusWord.12 THEN // Queries the DataTransferOK = TRUE bit from StatusWord
    ControlWord := 0; // Reset the ControlWord
    iStep       := 60; // Jump to the next step
```

END\_IF;

60:

```
IF NOT StatusWord.12 THEN // Query for completion of the data transfer,
                        // DataTransferOK = FALSE
    // Do other things... // Storage is completed
```

END\_IF;

END\_CASE

### 11.16.2 Loading a recipe

The following example code shows how process parameters can be loaded to the internal workpiece recipe.

```

CASE iStep OF
10:
    WorkpieceNo      := 3;      // Load third workpiece recipe
    ControlWord      := 1;      // Begins with the handshake
    iStep            := 20;     // Jump to the next step

20:
    IF StatusWord.12 THEN      // Queries the bit DataTransferOK=TRUE from StatusWord,
                                // Response of the product to transferred data
        ControlWord      := 0;  // Reset the ControlWord
        iStep            := 30;  // Jump to the next step
    END_IF;

30:
    IF NOT StatusWord.12 THEN  // Query for completion of the data transfer,
                                // DataTransferOK = FALSE
        // Do other things...   //Handshake is completed,
                                // Parameters from the third recipe have been taken over into the current process parameters.
    END_IF;
END_CASE
    
```

## 12 Operation

### INFORMATION



For selected products, the gripper jaws remain in their positions and the gripping force of the product stays constant.

The gripper jaws can be opened using the emergency release if the energy supply is lost.

This pertains to the products of the installation sizes GEH6xxxIL-03-B and GED6xxxIL-03-A.

- ▶ Please contact Customer Service if you have any questions.

### 12.1 Emergency release for GEH6000IL

#### CAUTION



#### Risk of injury due to uncontrolled movements

Risk of injury in the event of uncontrolled movement of the product when the power supply is connected.

- ▶ Switch off the power supply to the machine before carrying out any work.
- ▶ Secure the power supply against being switched on unintentionally.
- ▶ Check the machine for any residual energy that may be present.

#### CAUTION




#### Risk of injury in case of non-compliance

- ▶ Disconnect the actuator voltage before pressing the emergency release.

The product features an emergency release that can be mechanically opened with an Allen key in the event of a power failure.

- ▶ Remove the protective cap to reach the emergency release.
- ▶ Actuate the emergency release with a corresponding Allen key.
  - Turning counterclockwise opens the jaws (toward the BasePosition).
- ▶ Make sure that the workpiece is secured when opening the product.



| Design size    | Wrench size [mm] |
|----------------|------------------|
| GEH6040IL-03-B | 2.5              |
| GEH6040IL-31-B | 3                |
| GEH6060IL-03-B | 2.5              |
| GEH6060IL-31-B | 2                |
| GEH6140IL-03-B | 3                |
| GEH6180IL-03-B | 3                |

- ① Protective cap
- ② Allen key

### INFORMATION



- ▶ Carry out another reference run after any emergency release.
- ▶ Please contact Customer Service if you have any questions.

## 12.2 Emergency release for GED6000IL

### CAUTION



#### Risk of injury due to uncontrolled movements

Risk of injury in the event of uncontrolled movement of the product when the power supply is connected.

- ▶ Switch off the power supply to the machine before carrying out any work.
- ▶ Secure the power supply against being switched on unintentionally.
- ▶ Check the machine for any residual energy that may be present.

### CAUTION




#### Risk of injury in case of non-compliance

- ▶ Disconnect the actuator voltage before pressing the emergency release.

The product features an emergency release that can be mechanically opened with an Allen key in the event of a power failure.

- ▶ Remove the protective cap to reach the emergency release.
- ▶ Actuate the emergency release with a corresponding Allen key.
  - Turning counterclockwise opens the jaws (toward the BasePosition).
- ▶ Make sure that the workpiece is secured when opening the product.



| Design size    | Wrench size [mm] |
|----------------|------------------|
| GED6040IL-03-A | 2.5              |
| GED6040IL-31-A | 2                |
| GED6140IL-03-A | 3                |

- ① Protective cap
- ② Allen key

### INFORMATION



- ▶ Carry out another reference run after any emergency release.
- ▶ Please contact Customer Service if you have any questions.

## 13 Gripping force charts

### INFORMATION



- ▶ You can find the information in the technical data sheet on our website.
- ▶ Please contact Customer Service if you have any questions.

## 14 Error diagnosis

| Error code | Error   | Possible cause  | Measure  |
|------------|---|---|--|
| 0x0000     | Device is ready for operation.                      | -   | -  |
| 0x0001     | Motor controller is switched off.                   | <ul style="list-style-type: none"> <li>Motor controller has not yet been activated.</li> <li>Motor controller has been switched off.</li> <li>Motor controller was switched off for device protection.</li> </ul> | <ul style="list-style-type: none"> <li>Switch on the motor controller.</li> </ul>  |
| 0x0100     | Actuator power supply is not present or is too low. | <ul style="list-style-type: none"> <li>Actuator power supply is not connected</li> <li>Actuator power supply is not sufficient</li> <li>Cable break</li> <li>STO input circuit is interrupted.</li> </ul>         | <ul style="list-style-type: none"> <li>Check the actuator power supply.</li> <li>Switch on the STO input circuit.</li> </ul>                       |
| 0x0101     | Temperature above maximum permitted temperature.    | <ul style="list-style-type: none"> <li>Ambient temperature is too high</li> <li>Overload of the product</li> </ul>  | <ul style="list-style-type: none"> <li>Provide sufficient ventilation/cooling/connection.</li> <li>Check that the product moves freely.</li> </ul> |
| 0x0102     | Max. permitted temperature undershot                | <ul style="list-style-type: none"> <li>Ambient temperature is too low</li> </ul>  | <ul style="list-style-type: none"> <li>Provide an adequate operating temperature.</li> </ul>   |
| 0x0206     | Motion task cannot be executed (CRC error).         | <ul style="list-style-type: none"> <li>Internal error</li> </ul>  | <ul style="list-style-type: none"> <li>Apply the process data via a handshake.</li> <li>Please contact Customer Service.</li> </ul>                |
| 0x0300     | ControlWord is not plausible.                       | <ul style="list-style-type: none"> <li>Multiple bits were set in the ControlWord.</li> </ul>  | <ul style="list-style-type: none"> <li>In the ControlWord, check that only one bit is set.</li> </ul>  |
|            | Initial state after gripper restart                 | <ul style="list-style-type: none"> <li>Modified process data were not taken over.</li> </ul>  | <ul style="list-style-type: none"> <li>Apply the process data via a handshake.</li> </ul>  |
| 0x0301     | Positions implausible                               | <ul style="list-style-type: none"> <li>Transmitted positions are not plausible.</li> <li>Modified process data were not taken over.</li> </ul>  | <ul style="list-style-type: none"> <li>Check the transmitted process data.</li> <li>Apply the process data via a handshake.</li> </ul>             |
| 0x0302     | GripForce is not plausible.                         | <ul style="list-style-type: none"> <li>Transmitted GripForce is not plausible.</li> <li>Modified process data were not taken over.</li> </ul>   | <ul style="list-style-type: none"> <li>Check the transmitted process data.</li> <li>Apply the process data via a handshake.</li> </ul>             |
| 0x0303     | DriveVelocity not plausible                         | <ul style="list-style-type: none"> <li>Transmitted DriveVelocity is not plausible.</li> <li>Modified process data were not taken over.</li> </ul>   | <ul style="list-style-type: none"> <li>Check the transmitted process data.</li> <li>Apply the process data via a handshake.</li> </ul>             |
| 0x0304     | PositionTolerance is not plausible.                 | <ul style="list-style-type: none"> <li>Transmitted PositionTolerance is not plausible.</li> <li>Modified process data were not taken over.</li> </ul>   | <ul style="list-style-type: none"> <li>Check the transmitted process data.</li> <li>Apply the process data via a handshake.</li> </ul>             |

| Error code | Error                                     | Possible cause   | Measure  |
|------------|---|--|--|
| 0x0305     | Position measuring system not referenced. | <ul style="list-style-type: none"> <li>Position measuring system is not referenced.</li> <li>A reference run is being performed.</li> </ul>  | <ul style="list-style-type: none"> <li>▶ Reference the product.</li> <li>▶ Wait until the reference run is complete.</li> </ul>  |
| 0x0306     | DeviceMode is not plausible.              | <ul style="list-style-type: none"> <li>Transmitted DeviceMode is not plausible.</li> <li>Modified process data were not taken over.</li> </ul>   | <ul style="list-style-type: none"> <li>▶ Check the transmitted process data.</li> <li>▶ Apply the process data via a handshake.</li> </ul>   |
| 0x0307     | Motion task cannot be executed.           | <ul style="list-style-type: none"> <li>Multiple motion tasks in the same direction.                             <ul style="list-style-type: none"> <li>In DM6x, MoveToWork if ActualPosition &gt; WorkPosition</li> <li>In DM7x, MoveToBase if ActualPosition &lt; BasePosition</li> <li>In DM8x, MoveToWork if ActualPosition &gt; ShiftPosition</li> <li>In DM9x, MoveToBase if ActualPosition &lt; ShiftPosition</li> </ul> </li> </ul> | <ul style="list-style-type: none"> <li>▶ Reset the direction flag.                             <ul style="list-style-type: none"> <li>▶ Send the move command again.</li> </ul> </li> <li>▶ Position the product correctly before gripping.</li> </ul> |
| 0x0308     | WorkpieceNo cannot be selected.           | <ul style="list-style-type: none"> <li>Transmitted workpiece number is outside the permitted range.</li> <li>Modified process data were not taken over.</li> </ul>   | <ul style="list-style-type: none"> <li>▶ Check the transmitted process data.</li> <li>▶ Apply the process data via a handshake.</li> </ul>   |
| 0x0313     | Calculated ShiftPosition exceeded         | <ul style="list-style-type: none"> <li>Start position is not permitted for the selected motion task.</li> </ul>  | <ul style="list-style-type: none"> <li>▶ Move to the BasePosition with DeviceMode 60.</li> <li>▶ Move to the WorkPosition with DeviceMode 70.</li> </ul>   |
| 0x0402     | Jam                                       | <ul style="list-style-type: none"> <li>Gripper jaws are blocked.</li> <li>Gripper jaws are tensioned incorrectly.</li> </ul>   | <ul style="list-style-type: none"> <li>▶ Check that the product moves freely.</li> <li>▶ Send a motion task in the opposite direction.</li> </ul>  |
| 0x0404     | Position sensor error                     | <ul style="list-style-type: none"> <li>Fault of the integrated position sensor</li> </ul>  | <ul style="list-style-type: none"> <li>▶ Reference the product with a homing command.</li> <li>▶ Please contact Customer Service.</li> </ul>   |
| 0x0406     | Internal error                            | <ul style="list-style-type: none"> <li>Internal error</li> </ul>   | <ul style="list-style-type: none"> <li>▶ Please contact Customer Service.</li> </ul>   |
| 0x040B     | Internal error                            | <ul style="list-style-type: none"> <li>Internal error</li> </ul>   | <ul style="list-style-type: none"> <li>▶ Please contact Customer Service.</li> </ul>   |
| 0x040C     | Internal error                            | <ul style="list-style-type: none"> <li>Internal error</li> </ul>   | <ul style="list-style-type: none"> <li>▶ Please contact Customer Service.</li> </ul>   |
| 0x040D     | Internal error                            | <ul style="list-style-type: none"> <li>Internal error</li> </ul>   | <ul style="list-style-type: none"> <li>▶ Please contact Customer Service.</li> </ul>   |
| 0x040E     | Internal error                            | <ul style="list-style-type: none"> <li>Internal error</li> </ul>   | <ul style="list-style-type: none"> <li>▶ Please contact Customer Service.</li> </ul>   |

| Error code | Error          | Possible cause   | Measure  |
|------------|----------------|--|--|
| 0x040F     | Internal error | <ul style="list-style-type: none"> <li>Internal error</li> </ul> | <ul style="list-style-type: none"> <li>▶ Please contact Customer Service.</li> </ul> |

## 15 Table with acyclic data (ISDU)

### INFORMATION



IO-Link distinguishes between cyclical process data (PDU) and acyclic data (ISDU). Access to acyclic data is not arranged very conveniently for all control system and IO-Link master combinations. For this reason, the product can be used without acyclic data. This makes it as easy as possible to control the product.

► Please contact Customer Service if you have any questions.

### INFORMATION



► Note that the acyclic data with the following parameters correspond to the reflection of the process data:

- StatusWord, Diagnosis, ControlWord, ActualPosition, TeachPosition, WorkpieceNo, DeviceMode, PositionTolerance, GripForce, DriveVelocity, BasePosition, ShiftPosition, WorkPosition

| Index  | Name  | Data type | Access rights | Values          |
|--|---|-----------|---------------|-----------------|
| 0x0017 (23)  | Firmware version  | STRING    | Read          | -               |
|  | <b>Description</b>  |           |               |                 |
|  | Firmware version consists of four parts in the following sequence:                          |           |               |                 |
|  | Communication Firmware<br>Example:  |           |               |                 |
|  | <ul style="list-style-type: none"> <li>• Type: SWA000058</li> <li>• Version: R00</li> </ul> |           |               |                 |
|  | Application Firmware<br>Example:  |           |               |                 |
| <ul style="list-style-type: none"> <li>• Type: SWA000059</li> <li>• Version: P00</li> </ul>      |   |           |               |                 |
| Motor Control Firmware<br>Example:   |   |           |               |                 |
| <ul style="list-style-type: none"> <li>• Type: SWA000060</li> <li>• Version: D00</li> </ul>      |   |           |               |                 |
| Parameters<br>Example:   |   |           |               |                 |
| <ul style="list-style-type: none"> <li>• Type: PAR000059_04</li> <li>• Version: 10030</li> </ul> |   |           |               |                 |
| 0x0040 (64)  | StatusWord  | UINT16    | Read          | 0 - 65535       |
|  | <b>Description</b>  |           |               |                 |
| Read out the StatusWord  |   |           |               |                 |
| 0x0041 (65)  | Diagnosis   | UINT16    | Read          | 0 - 65535       |
|  | <b>Description</b>  |           |               |                 |
| Read out of the diagnostic code  |   |           |               |                 |
| 0x0042 (66)  | Cycle counter   | UINT32    | Read          | 0 to 4294967295 |
|  | <b>Description</b>  |           |               |                 |
| Read out of the total number of cycles   |   |           |               |                 |
| 0x0043 (67)  | Temperature   | UINT16    | Read          | 0 to 100 °C     |
|  | <b>Description</b>  |           |               |                 |
| Read out the current temperature   |   |           |               |                 |
| 0x0044 (68)  | ControlWord   | UINT16    | Read          | 0 - 65535       |
|  | <b>Description</b>  |           |               |                 |
| Read out of the ControlWord  |   |           |               |                 |



| Index        | Name  | Data type | Access rights | Values  |
|--------------|---|-----------|---------------|---|
| 0x0045 (69)  | Error code  | STRING    | Read          | -   |
|              | Description<br>Read out of the current error state  |           |               |   |
| 0x0046 (70)  | Error counter   | UINT32    | Read          | 0 to 4294967295                               |
|              | Description<br>Read out of the number of errors since the restart   |           |               |   |
| 0x0100 (256) | ActualPosition  | UINT16    | Read          | 0 to max. jaw stroke of the product [0,01 mm] |
|              | Description<br>Read out the current position of the gripper jaws  |           |               |   |
| 0x0101 (257) | TeachPosition   | UINT16    | Read          | 0 to max. jaw stroke of the product [0,01 mm] |
|              | Description<br>Read out of the current transmitted TeachPosition  |           |               |   |
| 0x0102 (258) | WorkpieceNo   | UINT8     | Read          | 0 - 32  |
|              | Description<br>Read out of the transmitted workpiece number   |           |               |   |
| 0x0103 (259) | DeviceMode  | UINT8     | Read          | 1-255   |
|              | Description<br>Read out of the transmitted travel mode  |           |               |   |
| 0x0104 (260) | PositionTolerance   | UINT8     | Read          | 0 to 255                                      |
|              | Description<br>Read out of the transmitted tolerance of the TeachPosition   |           |               |   |
| 0x0107 (263) | DriveVelocity   | UINT8     | Read          | 1 to 100 %                                    |
|              | Description<br>Read out of the transmitted movement speed   |           |               |   |
| 0x0108 (264) | BasePosition  | UINT16    | Read          | 0 to max. jaw stroke of the product [0,01 mm] |
|              | Description<br>Read out of the transmitted outer jaw position   |           |               |   |
| 0x0109 (265) | ShiftPosition   | UINT16    | Read          | 0 to max. jaw stroke of the product [0,01 mm] |
|              | Description<br>Read out of the transmitted toggle position  |           |               |   |
| 0x010A (266) | WorkPosition  | UINT16    | Read          | 0 to max. jaw stroke of the product [0,01 mm] |
|              | Description<br>Read out of the transmitted inner jaw position   |           |               |   |
| 0x0120 (288) | NoHomingAtStartup   | UINT8     | Read/write    | 0 to 1  |
|              | Description<br>For ISDU 288 = 1, the homing bit = 0 after the cold boot.<br>▶ Perform a homing after a cold start.<br>The product is delivered with ISDU 288 = 0.<br>This setting is stored in the product.<br>▶ Rewrite the values when replacing the product.<br>The function is available starting from Application Firmware Version SWA000059_P00 (see Index 0x0017). |           |               |   |

| Index   | Name        | Data type | Access rights | Values     |
|---|-------------|-----------|---------------|------------|
| 0x0121 (289)  | RegripForce | UINT8     | Read/write    | 1 to 100 % |
| <b>Description</b><br>The holding pressure current can be adapted for DeviceModes 64, 74, 84, 94.<br>The function is available starting from Application Firmware Version <i>SWA000059_P00</i> (see Index 0x0017).<br>The holding pressure current is not preset to the maximum possible value when shipped from the factory.<br>The maximum value can be changed via ISDU.<br>► Read the current settings in ISDU 289. <ul style="list-style-type: none"> <li>The factory setting is 90. Example: 90 % for GEH61xxIL-03-B.</li> </ul> ► Write the new values to ISDU 289. <ul style="list-style-type: none"> <li>The values can vary between 1 % and 100 %.</li> <li>► Do not use any amperages that are below the preset value.</li> </ul> ⇨ This setting is stored in the product.<br>► Rewrite the values when replacing the product.   |             |           |               |            |
| 0x0122 (290)  | ForceReset  | UINT8     | Read/write    | 0 to 1     |
| <b>Description</b><br>In DeviceModes 63, 64, 73, 74, 84, 85, 95, no unlocking operation is normally carried out. The <i>ForceReset</i> function makes it possible to carry out the unlocking operation.<br>The product is delivered with ForceReset = 0.<br>► Set ForceReset = 1 to request the unlocking operation.<br>⇨ This setting is stored in the product.<br>► Rewrite the values when replacing the product.<br>The function is available starting from Application Firmware Version <i>SWA000059_P00</i> (see Index 0x0017).   |             |           |               |            |
| 0x0123 (291)  | ForceMove   | UINT8     | Read/write    | 0 to 1     |
| <b>Description</b><br>If in DeviceModes 6x, the ActualPosition is greater than the WorkPosition, MovetoWork is not run and an error is generated (diagnostics 0x307).<br>If in DeviceModes 6x, the ActualPosition is less than the BasePosition, MovetoWork is not run and an error is generated (diagnostics 0x307).<br>The move command can be executed using the <i>ForceMove</i> function.<br>The product is delivered with ForceMove = 0.<br>► Set ISDU 291 = 1 to enable the move command.<br>⇨ This setting is stored in the product. <ul style="list-style-type: none"> <li>DeviceMode 6x - ActualPosition &gt; WorkPosition - MovetoWork<br/>                             ForceMove = 0: Move command is not executed (diagnostics 0x307).<br/>                             ForceMove = 1: Move command is executed.</li> <li>DeviceMode 7x - ActualPosition &lt; BasePosition - MovetoBase<br/>                             ForceMove = 0: Move command is not executed (diagnostics 0x307).<br/>                             ForceMove = 1: Move command is executed.</li> </ul> ► Rewrite the values when replacing the product.<br>The function is available starting from Application Firmware Version <i>SWA000059_P00</i> (see Index 0x0017). |             |           |               |            |

## 16 Maintenance

### NOTICE

**Material damage resulting from blowing out with compressed air**

Blowing out the product with compressed air can cause malfunctions.

- ▶ Never purge the product with compressed air.

### NOTICE

**Material damage caused by unsuitable cleaning materials**

Liquid and solvent-based cleaning agents can cause malfunctions.

- ▶ Do not clean the product with any cleaning agents that are liquid or contain solvents.

### NOTICE

**Contamination of the environment due to escaping lubricants**

Lubricants can escape through moving machine parts. This can lead to contamination of the machine, the workpiece and the environment.

- ▶ Remove leaking lubricant immediately and thoroughly.

Maintenance-free operation of the product is guaranteed for up to **5 million cycles**.

- ▶ Note that the product could become damaged under the following circumstances:
    - Dirty environment
    - Improper use and use that does not comply with the performance data
    - Permissible temperature range not observed
  - ▶ Even though the product is maintenance-free as mentioned above, perform a regular visual inspection to check for any damage or contamination.
  - ▶ Have maintenance work that requires disassembly of the product performed by customer service only.
- ⇒ Dismantling and reassembling the product without authorization may result in complications, as special installation equipment is required in some cases. Zimmer GmbH accepts no liability for any resulting malfunctions or damage.


### 16.1 Testing the STO safety function

In accordance with DIN EN ISO 13849-1, a test of the safety function must be carried out for an application using a control architecture of control category 2.

This test is carried out once a year for SIL 2 and once every 24 hours for SIL 3.

► Test the STO safety function for SIL 3 as part of daily maintenance work.

The figure shows the process for the test.



#### INFORMATION



- Document the result of the test in accordance with DIN EN ISO 13849-1, Section 10.
- Store this documentation in the general maintenance documents.

## 17 Decommissioning/disposal

### INFORMATION



When the product reaches the end of its operational phase, it can be completely disassembled and disposed of.

- ▶ Disconnect the product completely from the power supply.
- ▶ Dispose of the components properly according to the material groups.
- ▶ Comply with the locally applicable environmental and disposal regulations.

## 18 RoHS declaration

in terms of the EU Regulation 2011/65/EU

### Name and address of the manufacturer:

#### Zimmer GmbH

 Im Salmenkopf  
 77866 Rheinau, Germany  
 +49 7844 9138 0  
 [info@zimmer-group.com](mailto:info@zimmer-group.com)  
 [www.zimmer-group.com](http://www.zimmer-group.com)

We hereby declare that the incomplete machine described below

**Product designation:** 2-jaw parallel gripper/3-jaw concentric gripper, electric

**Type designation:** GEH6000IL, GED6000IL

conforms to the requirements of the directive in its design and the version we put on the market.

Michael Hoch

Authorized representative for the  
 compilation of relevant technical  
 documents

Rheinau, Germany, 2020-09-20

(Place and date of issuance)



Martin Zimmer  
 (Legally binding signature)  
 Managing Partner

## 19 Declaration of Incorporation

In terms of the EU Machinery Directive 2006/42/EC (Annex II 1 B)

### Name and address of the manufacturer:

**Zimmer GmbH**

 Im Salmenkopf  
 77866 Rheinau, Germany  
 +49 7844 9138 0  
 [info@zimmer-group.com](mailto:info@zimmer-group.com)  
 [www.zimmer-group.com](http://www.zimmer-group.com)

We hereby declare that the incomplete machine described below

**Product designation:** 2-jaw parallel gripper/3-jaw concentric gripper, electric  
**Type designation:** GEH6000IL, GED6000IL

conforms to the requirements of the Machinery Directive, 2006/42/EC, Article 2g, Annex VII, b – Annex II, b, in its design and the version we put on the market.

Basic health and safety requirements:

No. 1.1.2, No. 1.1.3, No. 1.1.5, No. 1.3.2, No. 1.3.4, No. 1.3.7, No. 1.3.9, No. 1.5.1, No. 1.5.2, No. 1.5.4, No. 1.6.4, No. 1.7.1, No. 1.7.4

A full list of applied standards can be obtained from the manufacturer.

We also declare that the specific technical documents were produced in accordance with Annex VII Part B of this Directive. We undertake to provide the market supervisory bodies with electronic versions of special documents for the incomplete machine through our documentation department, should they have reason to request them.


**The incomplete machine may only be commissioned if it has been ascertained, if applicable, that the machine or system in which the incomplete machine is to be installed satisfies the requirements of Directive 2006/42/EC on Machinery and an EC Declaration of Conformity has been drawn up in accordance with Annex II 1 A.**

Kurt Ross

Authorized representative for the compilation of relevant technical documents

Rheinau, Germany, 2021-06-04

(Place and date of issuance)



Martin Zimmer  
 (Legally binding signature)  
 Managing Partner

## 20 Declaration of Conformity

As defined by the EC Directive 2014/30/EU on electromagnetic compatibility

**Name and address of the manufacturer:**

**Zimmer GmbH**

 Im Salmenkopf  
 77866 Rheinau, Germany  
 +49 7844 9138 0  
 [info@zimmer-group.com](mailto:info@zimmer-group.com)  
 [www.zimmer-group.com](http://www.zimmer-group.com)

We hereby declare that the product described below

**Product designation:** 2-jaw parallel gripper/3-jaw concentric gripper, electric

**Type designation:** GEH6000IL, GED6000IL

conforms to the requirements of the Electromagnetic Compatibility Directive 2014/30/EU in its design and the version we put on the market.

The following harmonized standards have been used:

|                  |  |
|------------------|--|
| DIN EN ISO 12100 | Safety of machinery - General principles for design - Risk assessment and risk reduction |
| DIN EN 61000-6-3 | EMC Generic standard, Emission standard for residential, commercial and light-industrial |
| DIN EN 61000-6-2 | EMC Generic standard, Emission standard for industrial environments                      |
| DIN EN 61000-6-4 | EMC Generic standard, Immunity for industrial environments                               |

A full list of applied standards can be obtained from the manufacturer.

Kurt Ross  
 Authorized representative for the compilation of relevant technical documents

Rheinau, Germany, 2021-06-04  
 (Place and date of issuance)



Martin Zimmer  
 (Legally binding signature)  
 Managing Partner