

<Operationmanual\_Basic Gripping\_TIA\_V1\_21(EN).docx>

topic:

<FB Basic Gripping>

version:

<1>

status:

<21>

### History

Author	Reason for change/changes made	Release	Status	Date
Nock	Basic version	1	01	03.04.2019
Nock	Time-optimized, no handshake before motion commands	1	1	21.08.2019
Nock	Displaying parameter change with output bit Automatic reset of the direction flags	1	21	23.03.2020

## Content



1	Foreword.....	4
2	Integrating the library.....	4
3	MAIN.....	5
4	PLC variables.....	6
5	Using the function block.....	6
6	Functions of the function block.....	7
6.1	Resetting the step sequence „cmd_b_StepReset“ (BOOL).....	7
6.2	Transferring data with handshake „cmd_b_DataTransfer“ (BOOL) .....	8
6.3	Saving workpiece recipes „cmd_b_WritePDU“ (BOOL).....	8
6.4	Resetting the direction flags „cmd_b_ResetDirectionFlag“ (BOOL).....	8
6.5	Drive to BasePosition „cmd_b_MoveToBase“ (BOOL) .....	8
6.6	Drive to WorkPosition „cmd_b_MoveToWork“ (BOOL) .....	8
6.7	Limitting of the motion time „t_MotionTimeout“ (TIME) and „b_MotionError“ (BOOL) .....	8
6.8	Data transfer is required „b_DataTransferRequired“ (BOOL) .....	8
6.9	Error in the DataTransfer „b_DataTransferError“ (BOOL).....	9
6.10	Function block is busy „b_StepBusy“ (BOOL) .....	9
6.11	Ready for commands „b_StepDone“ (BOOL) .....	9
6.12	Bit 6 of the StatusWord „b_GripperPLCActive“ (BOOL) .....	9
6.13	Bit 8 of the StatusWord „b_BasePosition“ (BOOL) .....	9
6.14	Bit 9 of the StatusWord „b_TeachPosition“ (BOOL) .....	9
6.15	Bit 10 of the StatusWord „b_WorkPosition“ (BOOL) .....	9
6.16	Bit 11 of the StatusWord „b_UndefinedPosition“ (BOOL).....	9
6.17	Bit 12 of the StatusWord „b_DataTransferOK“ (BOOL) .....	9
6.18	Bit 13 of the StatusWord „b_ControlWord_100“ (BOOL).....	9
6.19	Bit 14 of the StatusWord „b_ControlWord_200“ (BOOL).....	9
6.20	Bit 15 of the StatusWord „b_Error“ (BOOL) and „n_Diagnose“ (UINT).....	9
6.21	n_ActualPosition (UINT) .....	10

### 1 Foreword

For using the example program at first a correct hardware configuration must be done. In this example is a Siemens CPU1212C DC/DC/DC with a Siemens IO Link master used. After the hardware settings the example project can be implemented. Please pass the following steps for that:

### 2 Integrating the library


Global libraries can be selected and integrated in the menu „Extra“ -> „Global libraries“ -> „Open library“. Please select the global library „ZG\_Basic\_Gripping\_TIA\_V1.21“.



On the right screen edge appears a new window where the global library can be selected and opened. Please select in the menu „Kopiervorlagen“ both data types („UDT\_Basic\_IN“ and „UDT\_Basic\_OUT“) and copy them under the section „PLC-datatypen“ to your project.



The function block „ZG\_FB\_Basic\_Gripping“ can be inserted under the section „Program blocks“.

These copy originals can be dragged per Drag & Drop to the PLC-datatypen.



### 3 MAIN

Please open the organization block „Main [OB1]“ under Program blocks und drag the function block „ZG\_FB\_Basic\_Gripping“ into the network.



Now the call options appear where a single instance is generated. You can name the instance „Gripper\_1“ for example. If you use more than one gripper, you'll need the same number of function blocks und you'll have to generate further instances.

Variables which are declared with „b\_“ are binary signals.

Variables which are declared with „cmd\_“ are command inputs. They can be controlled with a push button switch for example.

Variables which are declared with „n\_“ are input and output words or bytes. They are needed for transferring of the several positions and functions.

### 4 PLC variables

Under „PLC variables“ there are direct links with the gripper made. Please open the standard variable table under „PLC variables“ in the project navigation. You can declare two variables of the data type „UDT\_Basic\_IN“ and „UDT\_Basic\_OUT“ in the standard variable table. It's important to enter the correct address which you set in the hardware configuration for the inputs. In this case only the first address have to be inserted. The following addresses are generated and assigned automatically.

Test ▶ PLC\_1 [CPU 1212C DC/DC/DC] ▶ PLC-Variablen

PLC-Variablen

	Name	Datentyp ▲	Adresse	Rema...	Erreic...	Schrei...	Sichtb...	Kommentar
1	▶ UDT_BasicGripper1_IN	*UDT_Basic_IN*	%I8.0	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
2	▶ UDT_BasicGripper1_OUT	*UDT_Basic_OUT*	%Q8.0	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
3	<Hinzufügen>			<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	

### 5 Using the function block


On the inserted function block in chapter 3 are some inputs and outputs which must be wired. The input „UDT\_Gripper\_IN“ must be connected now with the belonging variable in chapter 4. The same must be done with the output variable „UDT\_Gripper\_OUT“. Now the function block can read the several states and positions of the gripper and can handle them. The output wiring of the gripper can also be parameterized.

For moving the gripper the several position data and options (drive profiles) have to be transfered. For standard values the following values in the table can be used. These are exemplary and can vary in different projects. You can set these parameters like in in our example on the block as constants or you can also use variables with the correct length that the wiring is flexible. If there is no wiring, the variables are preinitia-  
lised with the standard values.

n_DeviceMode	100 (1 at GEP/GED5000IL)
n_WorkpieceNo	0
n_TeachPosition	500
n_GripForce	1
n_PositionTolerance	50

The variable n\_DeviceMode corresponds to the drive profile of the gripper. These drive profiles can be found in the operation manual of the gripper. In this example DeviceMode 100 (at GEP2000IL or GPP5000IL) or 1 (at GEP/GED5000IL) was selected which corresponds to the drive profile „Universal operation“ and can be used as a standard value.

The completed function block should now look like in the following picture:



At last the settings have to be compiled and transfered to the device.

## 6 Functions of the function block

Depending on the wiring of the function block, several functions are carried out. You can find more information in the header of the block.

### 6.1 Resetting the step sequence „cmd\_b\_StepReset“ (BOOL)

The input variable „cmd\_b\_StepReset“ resets the step sequence in this function block. It doesn't depend on in which step the function block is at that moment. When the function block puts the error „b\_DataTransferError“ or „b\_MotionError“ out, it only can be resetted with this input.

### 6.2 Transferring data with handshake „cmd\_b\_DataTransfer“ (BOOL)

After each change of a process parameter (except "ControlWord") or during a cold start of the gripper, the parameters must be accepted with a data transfer. If the output variable "b\_DataTransferRequired" is "TRUE", the gripper hasn't worked with the currently set parameters yet. In this case the input "cmd\_b\_DataTransfer" must be triggered that the process parameters are transferred. Then the variable "b\_DataTransferRequired" changes to "FALSE". Thereby the "ControlWord" is set to value 1 and bit 12 of the "StatusWord" is waited for. Bit 12 becomes "TRUE" as soon as the data transfer is finished. Then the "ControlWord" is set to 0 again and waited until bit 12 becomes "FALSE". This procedure is a handshake and should be used for flawless data transmission.

### 6.3 Saving workpiece recipes „cmd\_b\_WritePDU“ (BOOL)

When this input is set to „TRUE“, the actual written process parameters at the input side of the function block are saved into the selected „WorkpieceNo“. This function sets the „ControlWord“ to the value 2 and waits for the bit 12 of the „StatusWord“. This procedure can last up to 30 seconds. The parameters are saved power failure safe in the gripper and they can be selected again with writing the „WorkpieceNo“. Up to 32 recipes can be saved in the gripper.

### 6.4 Resetting the direction flags „cmd\_b\_ResetDirectionFlag“ (BOOL)

When a gripper was moved to WorkPosition for example, the bit 14 of the „StatusWord“ is set. This signal keeps alive til a movement into the other direction or a new startup of the gripper. When a gripper must be driven to the same direction more than one time, this bit must be resetted before. This can be done with the input „cmd\_b\_ResetDirectionFlag“. This function sets the „ControlWord“ to the value 4 and waits for bit 13 and bit 14 of the „StatusWord“ becoming „FALSE“. After that it can be moved again into the same direction. Since the version 1.21 of the function block, this procedure has been carried out automatically before a movement of the gripper.

### 6.5 Drive to BasePosition „cmd\_b\_MoveToBase“ (BOOL)

When this input is set to „TRUE“, the gripper fingers move with the setted drive profile and grip force to the „BasePosition“. This function sets the „ControlWord“ to the value 256.

### 6.6 Drive to WorkPosition „cmd\_b\_MoveToWork“ (BOOL)

When this input is set to „TRUE“, the gripper fingers move with the setted drive profile and grip force to the „WorkPosition“. This function sets the „ControlWord“ to the value 512.

### 6.7 Limiting of the motion time „t\_MotionTimeout“ (TIME) and „b\_MotionError“ (BOOL)

If the gripper can't carry out a movement or can't reach the required destination, the step sequence will stop and the function block will be blocked for further commands. To avoid this struggle, the time „t\_MotionTimeout“ at the input can be defined. It is the maximum time which is allowed for the gripper's movement til arriving the position. It depends on the input parameters and have to be adjusted for your applikation. If the gripper doesn't reach its required destination in the setted time, the step sequence jumps into a error step. The output „b\_MotionError“ is set to „TRUE“ and only can be resetted again with the input „cmd\_b\_StepReset“.

### 6.8 Data transfer is required „b\_DataTransferRequired“ (BOOL)

The variable „b\_DataTransferError“ is active when at least on of the output variables which are sent to the gripper has been changed. As long as this variable is active, the gripper hasn't confirmed the changed values yet. For transferring the data the input variable „cmd\_b\_DataTransfer“ must be triggered. Then the variable „b\_DataTransferRequired“ changes to „FALSE“ and the gripper uses the actual set parameters.



#### 6.9 Error in the DataTransfer „b\_DataTransferError“ (BOOL)

The output „b\_DataTransferError“ is set to „TRUE“ when the data transfer („ControlWord“ = 1) couldn't be carried out successfully and the feedback of the gripper wasn't sent in the first second. There can be several reasons for this. An error code can be taken from the output „n\_Diagnose“. All the error codes are described in detail in the operation manual. This error can be resetted with setting the input „cmd\_b\_StepReset“.

#### 6.10 Function block is busy „b\_StepBusy“ (BOOL)

If the function block handles a command and is not in the initial step, this output is active and shows, that it is blocked for further commands.

#### 6.11 Ready for commands „b\_StepDone“ (BOOL)

If the function block is in the initial step and is ready for commands, this output is set to „TRUE“.

#### 6.12 Bit 6 of the StatusWord „b\_GripperPLCActive“ (BOOL)

This signal shows that the controller inside of the gripper is ready for operation. When the gripper is plugged in again or it is restarted after a voltage breakdown, the controller can only receive data when this signal is set again.

#### 6.13 Bit 8 of the StatusWord „b\_BasePosition“ (BOOL)

When the gripper reaches its defined „BasePosition“, this signal is activated. The size of the area is defined with the „PositionTolerance“.

#### 6.14 Bit 9 of the StatusWord „b\_TeachPosition“ (BOOL)

When the gripper reaches its defined „TeachPosition“, this signal is activated. The size of the area is defined with the „PositionTolerance“.

#### 6.15 Bit 10 of the StatusWord „b\_WorkPosition“ (BOOL)

When the gripper reaches its defined „WorkPosition“, this signal is activated. The size of the area is defined with the „PositionTolerance“.

#### 6.16 Bit 11 of the StatusWord „b\_UndefinedPosition“ (BOOL)

When the gripper stands still and is not on „BasePosition“, „TeachPosition“ or „WorkPosition“, this signal is „TRUE“.

#### 6.17 Bit 12 of the StatusWord „b\_DataTransferOK“ (BOOL)

With this bit the gripper gives feedback that a data transfer („ControlWord“ = 1) was carried out successfully. That's why it is used at a handshake procedure.

#### 6.18 Bit 13 of the StatusWord „b\_ControlWord\_100“ (BOOL)

This direction flag turns to „TRUE“ when the gripper got a „MoveToBase“ command. The gripper can't execute a further „MoveToBase“ command in this state. The flag is set to „FALSE“ again when the gripper gets a „MoveToWork“ command or a reset is done with „cmd\_b\_ResetDirectionFlag“ (see 6.4).

#### 6.19 Bit 14 of the StatusWord „b\_ControlWord\_200“ (BOOL)

This direction flag turns to „TRUE“ when the gripper got a „MoveToWork“ command. The gripper can't execute a further „MoveToWork“ command in this state. The flag is set to „FALSE“ again when the gripper gets a „MoveToBase“ command or a reset is done with „cmd\_b\_ResetDirectionFlag“ (see 6.4).

#### 6.20 Bit 15 of the StatusWord „b\_Error“ (BOOL) and „n\_Diagnose“ (UINT)

When the diagnose value of the gripper is not 0, this bit is set. The error code is put out in the data word „n\_Diagnose“. The descriptions to the error codes can be found in the operation manual.

#### **6.21 n\_ActualPosition (UINT)**

This data word shows the actual position of the gripper fingers.